

SYSMAC CP-series CP1E CPU Units

CP1E-E□□D□-□

CP1E-N□□D□-□/NA20D□-□

The CP1E Package PLCs: Economical, Easy to use, and Efficient

- The E-type Basic CPU Units provide cost performance and easy application with only basic functionality.
- The N and NA-types Application CPU Units support Programmable Terminal connection, position control, and inverter connection



CP1E-E20DR-A



CP1E-N40DR-A

Features

- Programming, setting, and monitoring with CX-Programmer.
- Easy connection with computers using commercially available USB cables
- With E30/40, N30/40/60 or NA20 CPU Units, Add I/O by Connecting Expansion I/O Units.
- With E30/40, N30/40/60 or NA20 CPU Units, Add Analog I/O or Temperature Inputs by Connecting Expansion Units.
- Quick-response inputs
- Input interrupts
- Complete High-speed Counter Functionality.
- Versatile pulse control for Transistor Output for N14/20/30/40/60 or NA20 CPU Units.
- PWM Outputs for Transistor Output for N14/20/30/40/60 or NA20 CPU Units.
- Built-in RS-232C Port for N/NA-type CPU Units.
- Mounting Serial Option Boards or Ethernet Option Board to N30/40/60 or NA20 CPU Units.
- Built-in analog I/O, two inputs and one output, for NA-type CPU Units.

System Configuration

The diagram illustrates the CP1E system architecture. On the left, a **Support Software CX-Programmer** (represented by a CD icon) and a **Personal computer** (labeled **IBM PC/AT or equivalent**) are connected to the **CP1E CPU Unit**. The CPU unit is shown with two models: **CP1E-E30DR-A** and **CP1E-E40DR-A**. Below the CPU unit, a smaller unit is shown, labeled **CP1E-E10□□□**, **CP1E-E14DR-A**, and **CP1E-E20DR-A**. To the right of the CPU unit is the **Expansion I/O Units** section, which includes **20 or 40 I/O Points** (8 inputs, 8 outputs, 16 outputs, 32 outputs) and **Expansion Units** (Analog I/O, Analog inputs, Analog outputs, Temperature sensors, CompoBus/S I/O Link Unit). A **DIN Track** is also shown. A bracket indicates that **Up to 3 Units can be connected**. A note states: **•When a two level layout is created by expansion and distance is required**. Below this, a **CP1E CPU Unit** is connected to **Expansion Units and Expansion I/O Units** using **I/O Connecting Cable** (**CP1W-CN811**).

The diagram illustrates the CP1E PLC system configuration and expansion options. It shows a central CP1E CPU Unit connected to various components:

- Battery:** CP1W-BAT01.
- Support Software:** CX-Programmer (IBM PC/AT or equivalent).
- Personal computer:** IBM PC/AT or equivalent.
- Expansion I/O Units:**
 - CP1E-N30D□-□
 - CP1E-N40D□-□
 - CP1E-N60D□-□
 - CP1E-NA20D□-□
- Expansion Units:**
 - 20 or 40 I/O Points
 - 8 inputs
 - 8 outputs
 - 16 outputs
 - 32 outputs
 - Analog I/O
 - Analog inputs
 - Analog outputs
 - Temperature sensors
 - CompoBus/S I/O Link Unit
- DIN Track:** CP1E-N14D□-□, CP1E-N20D□-□.
- Option Boards:**
 - RS-232C Option Board (CP1W-CIF01)
 - RS-422A/485 Option Board (CP1W-CIF11, CP1W-CIF12)
 - Ethernet Option Board (CP1W-CIF41)
- Other components:**
 - Programmable Terminal (PT) (NT Link/HOST Link)
 - General component (No-protocol mode)
 - Inverter (Modbus-RTU)
 - CP-series PLC or CJ1M PLC (Serial PLC Link)
 - Host computer (Host Link)

Additional information:






- Up to 3 Units can be connected.
- *The CP1W-DAM01 LCD Option Board can not be used.
- When a two level layout is created by expansion and distance is required, use the I/O Connecting Cable CP1W-CN811.

Ordering Information

International Standards






- The standards are abbreviated as follows: U: UL, U1: UL (Class I Division 2 Products for Hazardous Locations), C: CSA, UC: cULus, UC1: cULus (Class I Division 2 Products for Hazardous Locations), CU: cUL, N: NK, L: Lloyd, and CE: EC Directives.
- Contact your OMRON representative for further details and applicable conditions for these standards.



E-type CP1E CPU Units (Basic Models)

| Product name | Specifications | | | | | | External power supply (24 VDC) (A) | Current consumption (A) | | Model | Standards |
|---|----------------|--------|---------|-----------------------|------------------|----------------------|------------------------------------|-------------------------|------|---|---------------|
| | Power Supply | Inputs | Outputs | Output type | Program capacity | Data memory capacity | | 5 V | 24 V | | |
| E-type CPU Units with 10 I/O Points  | 100 to 240 VAC | 6 | 4 | Relay | 2K steps | 2K words | -- | 0.08 | 0.04 | CP1E-E10DR-A <i><u>NEW</u></i> | UC1, N, L, CE |
| | | | | Transistor (sinking) | | | -- | 0.11 | -- | CP1E-E10DT-A <i><u>NEW</u></i> | |
| | | | | Transistor (sourcing) | | | -- | 0.11 | -- | CP1E-E10DT1-A <i><u>NEW</u></i> | |
| | 24 VDC | | | Relay | | | -- | 0.08 | 0.04 | CP1E-E10DR-D <i><u>NEW</u></i> | |
| | | | | Transistor (sinking) | | | -- | 0.11 | -- | CP1E-E10DT-D <i><u>NEW</u></i> | |
| | | | | Transistor (sourcing) | | | -- | 0.11 | -- | CP1E-E10DT1-D <i><u>NEW</u></i> | |
| E-type CPU Units with 14 I/O Points  | 100 to 240 VAC | 8 | 6 | Relay | 2K steps | 2K words | -- | 0.16 | 0.07 | CP1E-E14DR-A <i><u>NEW</u></i> | UC1, N, L, CE |
| E-type CPU Units with 20 I/O Points  | 100 to 240 VAC | 12 | 8 | Relay | 2K steps | 2K words | -- | 0.17 | 0.08 | CP1E-E20DR-A | UC1, N, L, CE |
| E-type CPU Units with 30 I/O Points  | 100 to 240 VAC | 18 | 12 | Relay | 2K steps | 2K words | 0.30 | 0.17 | 0.07 | CP1E-E30DR-A | UC1, N, L, CE |
| E-type CPU Units with 40 I/O Points  | 100 to 240 VAC | 24 | 16 | Relay | 2K steps | 2K words | 0.30 | 0.17 | 0.09 | CP1E-E40DR-A | UC1, N, L, CE |

Note: There are no accessories included with E-type CP1E CPU Units. A Battery (CP1W-BAT01) cannot be used.

N/NA-type CP1E CPU Units (Application Models)





| Product name | Specifications | | | | | | External power supply (24 VDC) (A) | Current consumption (A) | | Model | Standards |
|---|----------------|--------|---------|-----------------------|------------------|----------------------|------------------------------------|-------------------------|------|---------------------------------|---------------|
| | Power Supply | Inputs | Outputs | Output type | Program capacity | Data memory capacity | | 5 V | 24 V | | |
| N-type CPU Units with 14 I/O Points  | 100 to 240 VAC | 8 | 6 | Relay | 8K steps | 8K words | -- | 0.17 | 0.07 | CP1E-N14DR-A <u>NEW</u> | UC1, N, L, CE |
| | 24 VDC | | | Transistor (sinking) | | | -- | 0.22 | 0.02 | CP1E-N14DT-A <u>NEW</u> | |
| | | | | Transistor (sourcing) | | | -- | 0.22 | 0.02 | CP1E-N14DT1-A <u>NEW</u> | |
| | | | | Relay | | | -- | 0.17 | 0.07 | CP1E-N14DR-D <u>NEW</u> | |
| | | | | Transistor (sinking) | | | -- | 0.22 | 0.02 | CP1E-N14DT-D <u>NEW</u> | |
| | | | | Transistor (sourcing) | | | -- | 0.22 | 0.02 | CP1E-N14DT1-D <u>NEW</u> | |
| N-type CPU Units with 20 I/O Points  | 100 to 240 VAC | 12 | 8 | Relay | 8K steps | 8K words | -- | 0.18 | 0.08 | CP1E-N20DR-A | UC1, N, L, CE |
| | 24 VDC | | | Transistor (sinking) | | | -- | 0.23 | 0.02 | CP1E-N20DT-A | |
| | | | | Transistor (sourcing) | | | -- | 0.23 | 0.02 | CP1E-N20DT1-A | |
| | | | | Relay | | | -- | 0.18 | 0.08 | CP1E-N20DR-D | |
| | | | | Transistor (sinking) | | | -- | 0.23 | 0.02 | CP1E-N20DT-D | |
| | | | | Transistor (sourcing) | | | -- | 0.23 | 0.02 | CP1E-N20DT1-D | |
| N-type CPU Units with 30 I/O Points  | 100 to 240 VAC | 18 | 12 | Relay | 8K steps | 8K words | 0.30 | 0.21 | 0.07 | CP1E-N30DR-A | UC1, N, L, CE |
| | 24 VDC | | | Transistor (sinking) | | | 0.30 | 0.27 | 0.02 | CP1E-N30DT-A | |
| | | | | Transistor (sourcing) | | | 0.30 | 0.27 | 0.02 | CP1E-N30DT1-A | |
| | | | | Relay | | | -- | 0.21 | 0.07 | CP1E-N30DR-D | |
| | | | | Transistor (sinking) | | | -- | 0.27 | 0.02 | CP1E-N30DT-D | |
| | | | | Transistor (sourcing) | | | -- | 0.27 | 0.02 | CP1E-N30DT1-D | |
| N-type CPU Units with 40 I/O Points  | 100 to 240 VAC | 24 | 16 | Relay | 8K steps | 8K words | 0.30 | 0.21 | 0.09 | CP1E-N40DR-A | UC1, N, L, CE |
| | 24 VDC | | | Transistor (sinking) | | | 0.30 | 0.31 | 0.02 | CP1E-N40DT-A | |
| | | | | Transistor (sourcing) | | | 0.30 | 0.31 | 0.02 | CP1E-N40DT1-A | |
| | | | | Relay | | | -- | 0.21 | 0.09 | CP1E-N40DR-D | |
| | | | | Transistor (sinking) | | | -- | 0.31 | 0.02 | CP1E-N40DT-D | |
| | | | | Transistor (sourcing) | | | -- | 0.31 | 0.02 | CP1E-N40DT1-D | |
| N-type CPU Units with 60 I/O Points  | 100 to 240 VAC | 36 | 24 | Relay | 8K steps | 8K words | 0.30 | 0.21 | 0.13 | CP1E-N60DR-A <u>NEW</u> | UC1, N, L, CE |
| | 24 VDC | | | Transistor (sinking) | | | 0.30 | 0.31 | 0.02 | CP1E-N60DT-A <u>NEW</u> | |
| | | | | Transistor (sourcing) | | | 0.30 | 0.31 | 0.02 | CP1E-N60DT1-A <u>NEW</u> | |
| | | | | Relay | | | -- | 0.21 | 0.13 | CP1E-N60DR-D <u>NEW</u> | |
| | | | | Transistor (sinking) | | | -- | 0.31 | 0.02 | CP1E-N60DT-D <u>NEW</u> | |
| | | | | Transistor (sourcing) | | | -- | 0.31 | 0.02 | CP1E-N60DT1-D <u>NEW</u> | |

| Product name | Specifications | | | | | | External power supply (24 VDC) (A) | Current consumption (A) | | Model | Standards |
|---|--|---------------------------------------|---------------------------------------|-----------------------|------------------|----------------------|------------------------------------|-------------------------|------|---------------------------|---------------|
| | Power Supply | Inputs | Outputs | Output type | Program capacity | Data memory capacity | | 5 V | 24 V | | |
| NA-type CPU Units with 20 I/O Points (Built-in analog)  | 100 to 240 VAC | 12 (Built-in analog inputs: 2) | 8 (Built-in analog outputs: 1) | Relay | 8K steps | 8K words | 0.30 | 0.18 | 0.11 | CP1E-NA20DR-A <u>NEW</u> | UC1, N, L, CE |
| | 24 VDC | | | Transistor (sinking) | | | -- | 0.23 | 0.09 | CP1E-NA20DT-D <u>NEW</u> | |
| | | | | Transistor (sourcing) | | | -- | 0.23 | 0.09 | CP1E-NA20DT1-D <u>NEW</u> | |
| Battery Set  | For N/NA-type CP1E CPU Units Note: Mount a Battery to an N/NA-type CPU Unit if the data in the following areas must be backed up for power interruptions. <ul style="list-style-type: none">DM Area (D) (except backed up words in the DM Area), Holding Area (H), Counter Completion Flags (C), Counter Present Values (C), Auxiliary Area (A), and Clock Function (Use batteries within two years of manufacture.) | | | | | | | | | CP1W-BAT01 | CE |

Note: There are no accessories included with N/NA-type CP1E CPU Units. RS-232C connectors for the built-in RS-232C port and the Battery (CP1W-BAT01) are not included.

Options (for CP1E N30/40/60 or NA20 CPU Units)

The Options cannot be used for CP1E N14/20 CPU Units and all E-type CPU Units.

| Product name | Specifications | Model | Standards |
|--|---|-------------------|---------------|
| RS-232C Option Board  | One RS-232C Option Board can be mounted to the Option Board slot. For CP1E N30/40/60 or NA20 CPU Units only. One RS-232C connector is included. | CP1W-CIF01 | UC1, N, L, CE |
| RS-422A/485 Option Board  | One RS-422A/485 Option Board can be mounted to the Option Board slot. For CP1E N30/40/60 or NA20 CPU Units only. | CP1W-CIF11 | |
| RS-422A/485 Isolated-type Option Board  | | CP1W-CIF12 | UC1, N, L, CE |
| Ethernet Option Board  | One Ethernet Option Board can be mounted to the Option Board slot. CP1E CPU Units are supported by CP1W-CIF41 version 2.0 or higher. For CP1E N30/40/60 or NA20 CPU Units only. When using CP1W-CIF41, CX-Programmer version 9.12 or higher is required. | CP1W-CIF41 | UC1, N, L, CE |

Note: It is not possible to use a CP-series Ethernet Option Board version 1.0 (CP1W-CIF41), LCD Option Board (CP1W-DAM01), or Memory Card (CP1W-ME05M) with a CP1E CPU Unit.

Programming Devices

| Product name | Specifications | Media | | Model | Standards |
|---|--|--------------------|-------|-----------------------|-----------|
| | | Number of licenses | | | |
| FA Integrated Tool Package CX-One Lite Ver.4.□ | CX-One Lite is a subset of the complete CX-One package that provides only the Support Software required for micro PLC applications. CX-One Lite runs on the following OS. Windows 2000 (Service Pack 4 or higher), XP, Vista, or 7 Note: Except for 64-bit version. CX-One Lite Ver. 4.□ includes Micro PLC Edition CX-Programmer Ver.9.□. | 1 license | CD | CXONE-LT01C-V4 | -- |
| FA Integrated Tool Package CX-One Package Ver. 4.□ | CX-One is a comprehensive software package that integrates Support Software for OMRON PLCs and components. CX-One runs on the following OS. OS: Windows 2000 (Service Pack 4 or higher), XP, Vista, or 7 Note: Except for 64-bit version. CX-One Ver. 4.□ includes CX-Programmer Ver. 9.□. | 1 license *1 | DVD*2 | CXONE-AL01D-V4 | -- |

Note: 1. The E20, E30, E40, N20, N30 and N40 CPU Units are supported by CX-Programmer version 8.2 or higher.

The E10, E14, N14, N60, and NA20 CPU Units are supported by CX-Programmer version 9.03 or higher.

When Micro PLC Edition CX-Programmer is used, you need version 9.03 or higher.

2. The CX-One and CX-One Lite cannot be simultaneously installed on the same computer.

* 1 Multi licenses are available for the CX-One (3, 10, 30 or 50 licenses).

* 2 The CX-One is also available on CD (CXONE-AL□□C-V4).




The following tables lists the Support Software that can be installed from CX-One

| Support Software in CX-One | | CX-One Lite Ver.4.□ | CX-One Ver.4.□ | Support Software in CX-One | | CX-One Lite Ver.4.□ | CX-One Ver.4.□ |
|---------------------------------|---------|---------------------|----------------|-------------------------------|---------|---------------------|----------------|
| Micro PLC Edition CX-Programmer | Ver.9.□ | Yes | No | CX-Drive | Ver.1.□ | Yes | Yes |
| CX-Programmer | Ver.9.□ | No | Yes | CX-Process Tool | Ver.5.□ | No | Yes |
| CX-Integrator | Ver.2.□ | Yes | Yes | Faceplate Auto-Builder for NS | Ver.3.□ | No | Yes |
| Switch Box Utility | Ver.1.□ | Yes | Yes | CX-Designer | Ver.3.□ | Yes | Yes |
| CX-Protocol | Ver.1.□ | No | Yes | NV-Designer | Ver.1.□ | Yes | Yes |
| CX-Simulator | Ver.1.□ | Yes | Yes | CX-Thermo | Ver.4.□ | Yes | Yes |
| CX-Position | Ver.2.□ | No | Yes | CX-ConfiguratorFDT | Ver.1.□ | Yes | Yes |
| CX-Motion-NCF | Ver.1.□ | No | Yes | CX-FLnet | Ver.1.□ | No | Yes |
| CX-Motion-MCH | Ver.2.□ | No | Yes | Network Configurator | Ver.3.□ | Yes | Yes |
| CX-Motion | Ver.2.□ | No | Yes | CX-Server | Ver.4.□ | Yes | Yes |

Note: For details, refer to the CX-One Catalog (Cat. No. R134).

Expansion I/O Units and Expansion Units (for CP1E E30/40, N30/40/60, or NA20 CPU Units)

CP1E E10/14/20 or N14/20 CPU Units do not support Expansion I/O Units and Expansion Units.

| Unit type | Product name | Specifications | | | Current consumption (A) | | Model | Standards | |
|--------------------------------|---|--|---------|-----------------------|-------------------------|-------|---------------------------|----------------|----------|
| | | Inputs | Outputs | Output type | 5 V | 24 V | | | |
| CP1W Expansion I/O Units | Input Unit  | 8 | -- | -- | 0.018 | -- | CP1W-8ED | U, C, N, L, CE | |
| | Output Units  | -- | 8 | Relay | 0.026 | 0.044 | CP1W-8ER | | |
| | | | | Transistor (sinking) | 0.075 | -- | CP1W-8ET | | |
| | | | | Transistor (sourcing) | 0.075 | -- | CP1W-8ET1 | | |
| |  | -- | 16 | Relay | 0.042 | 0.090 | CP1W-16ER | N, L, CE | |
| | | | | Transistor (sinking) | 0.076 | -- | CP1W-16ET | | |
| | | | | Transistor (sourcing) | 0.076 | -- | CP1W-16ET1 | | |
| |  | -- | 32 | Relay | 0.049 | 0.131 | CP1W-32ER | N, L, CE | |
| | | | | Transistor (sinking) | 0.113 | -- | CP1W-32ET | | |
| | | | | Transistor (sourcing) | 0.113 | -- | CP1W-32ET1 | | |
| | I/O Units  | 12 | 8 | Relay | 0.103 | 0.044 | CP1W-20EDR1 | U, C, N, L, CE | |
| | | | | Transistor (sinking) | 0.130 | -- | CP1W-20EDT | | |
| | | | | Transistor (sourcing) | 0.130 | -- | CP1W-20EDT1 | | |
| | |  | 24 | 16 | Relay | 0.080 | 0.090 | CP1W-40EDR | N, L, CE |
| | | | | | Transistor (sinking) | 0.160 | -- | CP1W-40EDT | |
| | | | | | Transistor (sourcing) | 0.160 | -- | CP1W-40EDT1 | |
| CP1W Expansion Units | Analog Input Unit  | 4 analog inputs Input range: 0 to 5 V, 1 to 5 V, 0 to 10 V, ± 10 V, 0 to 20 mA, or 4 to 20 mA. Resolution: 1/6000 | | | 0.100 | 0.090 | CP1W-AD041 | UC1, N, L, CE | |
| | Analog Output Unit  | 2 analog outputs Output range: 1 to 5 V, 0 to 10 V, ± 10 V, 0 to 20 mA, or 4 to 20 mA. Resolution: 1/6000 | | | 0.040 | 0.095 | CP1W-DA021 ^{NEW} | UC1, CE | |
| | | 4 analog outputs Output range: 1 to 5 V, 0 to 10 V, ± 10 V, 0 to 20 mA, or 4 to 20 mA. Resolution: 1/6000 | | | 0.080 | 0.124 | CP1W-DA041 | UC1, N, L, CE | |
| | Analog I/O Unit  | 2 analog inputs and 1 analog output Input range: 0 to 5 V, 1 to 5 V, 0 to 10 V, ± 10 V, 0 to 20 mA, or 4 to 20 mA. Output range: 1 to 5 V, 0 to 10 V, ± 10 V, 0 to 20 mA, or 4 to 20 mA. Resolution: 1/6000 | | | 0.083 | 0.110 | CP1W-MAD11 | U, C, N, L, CE | |
| | Temperature Sensor Unit  | 2 temperature sensor inputs Sensor type: Thermocouple (J or K) | | | 0.040 | 0.059 | CP1W-TS001 | | |
| | | 4 temperature sensor inputs Sensor type: Thermocouple (J or K) | | | 0.040 | 0.059 | CP1W-TS002 | | |
| | | 2 temperature sensor inputs Sensor type: Platinum resistance thermometer (Pt100 or JPt100) | | | 0.054 | 0.073 | CP1W-TS101 | | |
| | | 4 temperature sensor inputs Sensor type: Platinum resistance thermometer (Pt100 or JPt100) | | | 0.054 | 0.073 | CP1W-TS102 | | |
| | CompoBus/S I/O Link Unit  | CompoBus/S slave 8 inputs and 8 outputs | | | 0.029 | -- | CP1W-SRT21 | | |

I/O Connecting Cable

| Product name | Specifications | Model | Standards |
|----------------------|--|------------|---------------|
| I/O Connecting Cable | 80 cm (for CP1W Expansion I/O Units and Expansion Units) Only one I/O Connecting Cable can be used in each PLC. | CP1W-CN811 | UC1, N, L, CE |

Note: An I/O Connecting Cable (approx. 6 cm) for horizontal connection is provided with CP1W Expansion I/O Units and Expansion Units.

CP1E-E□□D□-□ CP1E-N□□D□-□/NA20D□-□

General Specifications

| Type | | AC power supply models | DC power supply models |
|---------------------------|-------------------------------|--|--|
| Model | | CP1E-□□□D□-A | CP1E-□□□D□-D |
| Enclosure | | Mounted in a panel | |
| Dimensions (H × D × W) | | CPU Unit with 10 I/O points (CP1E-E10D□-□): 90mm *1 ×85mm *2 × 66 mm CPU Unit with 14 or 20 I/O points (CP1E-□14D□-□/□20D□-□): 90mm *1 × 85mm *2 × 86 mm CPU Unit with 30 I/O points (CP1E-□30D□-□): 90mm *1 × 85mm *2 × 130 mm CPU Unit with 40 I/O points (CP1E-□40D□-□): 90mm *1 × 85mm *2 × 150 mm CPU Unit with 60 I/O points (CP1E-N60D□-□): 90mm *1 ×85mm *2 × 195 mm CPU Unit with 20 I/O points and built-in analog (CP1E-NA20D□-□): 90mm *1 ×85mm *2 × 130 mm | |
| Weight | | CPU Unit with 10 I/O points (CP1E-E10D□-□): 300g max. CPU Unit with 14 I/O points (CP1E-□14D□-□): 360g max. CPU Unit with 20 I/O points (CP1E-□20D□-□): 370g max. CPU Unit with 30 I/O points (CP1E-□30D□-□): 600g max. CPU Unit with 40 I/O points (CP1E-□40D□-□): 660g max. CPU Unit with 60 I/O points (CP1E-N60D□-□): 850g max. CPU Unit with 20 I/O points and built-in analog (CP1E-NA20D□-□): 680g max. | |
| Electrical specifications | Supply voltage | 100 to 240 VAC 50/60 Hz | 24 VDC |
| | Operating voltage range | 85 to 264 VAC | 20.4 to 26.4 VDC |
| | Power consumption | 15 VA/100 VAC max. 25 VA/240 VAC max. (CP1E-E10D□-A/□14D□-A/□20D□-A) | 9 W max. (CP1E-E10D□-D) 13 W max. (CP1E-N14D□-D/N20D□-D) |
| | | 50 VA/100 VAC max. 70 VA/240 VAC max. (CP1E-NA20D□-A/□30D□-A/□40D□-A/N60D□-A) | 20 W max. (CP1E-NA20D□-D/N30D□-D/N40D□-D/N60D□-D) *4 |
| | Inrush current | 120 VAC, 20 A for 8 ms max. for cold start at room temperature 240 VAC, 40 A for 8 ms max. for cold start at room temperature | 24 VDC, 30 A for 20 ms max. for cold start at room temperature |
| | External power supply *3 | Not provided. (CP1E-E10D□-A/□14D□-A/□20D□-A) 24 VDC, 300 mA (CP1E-NA20D□-A/□30D□-A/□40D□-A/N60D□-A) | Not provided |
| | Insulation resistance | 20 MΩ min. (at 500 VDC) between the external AC terminals and GR terminals | Except between DC primary current and DC secondary current |
| | Dielectric strength | 2,300 VAC 50/60Hz for 1 min between AC external and GR terminals Leakage current: 5 mA max. | Except between DC primary current and DC secondary current |
| Application environment | Power OFF detection time | 10 ms min. | 2 ms min. |
| | Ambient operating temperature | 0 to 55 °C | |
| | Ambient humidity | 10% to 90% | |
| | Atmosphere | No corrosive gas. | |
| | Ambient storage temperature | -20 to 75 °C (excluding battery) | |
| | Altitude | 2,000 m max. | |
| | Pollution degree | 2 or less: Conforms to JIS B3502 and IEC 61131-2. | |
| | Noise resistance | 2 kV on power supply line (Conforms to IEC61000-4-4.) | |
| | Overvoltage category | Category II: Conforms to JIS B3502 and IEC 61131-2. | |
| | EMC Immunity Level | Zone B | |
| | Vibration resistance | Conforms to JIS 60068-2-6. 5 to 8.4 Hz with 3.5-mm amplitude, 8.4 to 150 Hz Acceleration of 9.8 m/s ² for 100 min in X, Y, and Z directions (10 sweeps of 10 min each = 100 min total) | |
| | Shock resistance | Conforms to JIS 60068-2-27. 147 m/s ² , 3 times in X, Y, and Z directions | |
| Terminal block | | Fixed (not removable) | |
| Terminal screw size | | M3 | |
| Applicable standards | | Conforms to EC Directive | |
| Grounding method | | Ground to 100 Ω or less. | |

* 1 Total of 110 mm with mounting brackets.

* 2 Excluding cables.

* 3 Use the external power supply to power input devices. Do not use it to drive output devices.

* 4 This is the rated value for the maximum system configuration. Use the following formula to calculate power consumption for CPU Units with DC power.

Formula: DC power consumption = (5V current consumption × 5 V/70% (internal power efficiency) + 24V current consumption) × 1.1 (current fluctuation factor)

The above calculation results show that a DC power supply with a greater capacity is required.

Performance Specifications

| Item | | | CP1E-□□D□-□ | CP1E-N□□D□-□ CP1E-NA□□D□-□ |
|---|---|---|---|--|
| Program capacity | | | 2 K steps (8 Kbytes) including the symbol table, comments, and program indices of the CX-Programmer | 8 K steps (32 Kbytes) including the symbol table, comments, and program indices of the CX-Programmer |
| Control method | | | Stored program method | |
| I/O control method | | | Cyclic scan with immediate refreshing | |
| Program language | | | Ladder diagram | |
| Instructions | | | Approximately 200 | |
| Processing speed | Overhead processing time | | 0.4 ms | |
| | Instruction execution times | | Basic instructions (LD): 1.19 μs min. Special instructions (MOV): 7.9 μs min. | |
| Number of CP1W-series Expansion Units connected | | | CP1E-E10D□-□/□14D□-□/□20D□-□: None CP1E-□30D□-□/□40D□-□/□N60D□-□/□NA20D□-□: 3 units | |
| Maximum number of I/O points | | | CP1E-E10D□-□ : 10 CP1E-□14D□-□ : 14 CP1E-□20D□-□ : 20 CP1E-□30D□-□ : 150 (30 built in, 40 × 3 expansion) CP1E-□40D□-□ : 160 (40 built in, 40 × 3 expansion) CP1E-N60D□-□ : 180 (60 built in, 40 × 3 expansion) CP1E-NA20D□-□: 140 (20 built in, 40 × 3 expansion) | |
| Built-in I/O | | | CP1E-E10D□-□ : 10 (6 inputs, 4 outputs) CP1E-□14D□-□ : 14 (8 inputs, 6 outputs) CP1E-□20D□-□ : 20 (12 inputs, 8 outputs) CP1E-□30D□-□ : 30 (18 inputs, 12 outputs) CP1E-□40D□-□ : 40 (24 inputs, 16 outputs) CP1E-N60D□-□ : 60 (36 inputs, 24 outputs) CP1E-NA20D□-□: 20 (12 inputs, 8 outputs) | |
| Built-in input functions | High-speed counters | High-speed counter mode/maximum frequency | Incremental Pulse Inputs 10 kHz: 6 counters 5 counters (only for 10 I/O points) Up/Down Inputs 10 kHz: 2 counters Pulse + Direction Inputs 10 kHz: 2 counters Differential Phase Inputs (4x) 5 kHz: 2 counters | Incremental Pulse Inputs 100 kHz: 2 counters,10 kHz: 4 counters Up/Down Inputs 100 kHz: 1 counters,10 kHz: 1 counters Pulse + Direction Inputs 100 kHz: 2 counters Differential Phase Inputs (4x) 50 kHz: 1 counter, 5 kHz: 1 counter |
| | | Counting mode | Linear mode Ring mode | |
| | | Count value | 32 bits | |
| | | Counter reset modes | Phase Z and software reset (excluding increment pulse input) Software reset | |
| | | Control method | Target Matching Range Comparison | |
| | Input interrupts | | 6 inputs (4 inputs only for 10 I/O points) Interrupt input pulse width: 50 μs min. | |
| | Quick-response Inputs | | 6 inputs (4 inputs only for 10 I/O points) Input pulse width: 50 μs min. | |
| | Normal input | Input constants | Delays can be set in the PLC Setup (0 to 32 ms, default: 8 ms). Set values: 0, 1, 2, 4, 8, 16, or 32 ms | |
| Built-in output functions | Pulse outputs (Models with transistor outputs only) | Pulse output method and output frequency | Pulse output function not included | Pulse + Direction Mode 1 Hz to 100 kHz: 2 outputs |
| | | Output mode | | Continuous mode (for speed control) Independent mode (for position control) |
| | | Number of output pulses | | Relative coordinates: 0000 0000 to 7FFF FFFF hex (0 to 2147483647) Absolute coordinates: 8000 0000 to 7FFF FFFF hex (-2147483647 to 2147483647) |
| | | Acceleration/deceleration curves | | Trapezoidal acceleration and deceleration (Cannot perform S-curve acceleration and deceleration.) |
| | | Changing SVs during instruction execution | | Only target position can be changed. |
| | | Origin searches | | Included |
| | Pulse outputs (Models with transistor outputs only) | Frequency | PWM output function not included | 2.0 to 6,553.5 Hz (in increments of 0.1 Hz) with 1 output or 2 Hz to 32,000 Hz (in increments of 1 Hz) with 1 output |
| | | Duty factor | | 0.0% to 100.0% (in increments of 0.1%) Accuracy: +1%/-0% at 2 Hz to 10,000 Hz and +5%/-0% at 10,000 Hz to 32,000 kHz |
| | | Output mode | | Continuous Mode |
| Built-in analog | | Analog input | Setting range: 0 to 6,000 (2 channels only for NA-type) | |
| | | Analog output | Setting range: 0 to 6,000 (1 channels only for NA-type) | |
| Analog adjusters | | | 2 adjusters (Setting range: 0 to 255) | |

CP1E-E□□D□-□ CP1E-N□□D□-□/NA20D□-□

| Item | | CP1E-E□□D□-□ | CP1E-N□□D□-□ CP1E-NA□□D□-□ |
|--|---|---|--|
| Communications | B-type Peripheral USB Port | | Conforming to USB 2.0 B type connector |
| | | Transmission distance | 5 m max. |
| | Built-in RS-232C port | | Interface: Conforms to EIA RS-232C. |
| | | Communications method | Half duplex |
| | | synchronization | Start-stop |
| | | Baud rate | 1.2, 2.4, 4.8, 9.6, 19.2, 38.4, 57.6, or 115.2 kbps |
| | | Transmission distance | 15 m max. |
| | | Supported protocol | <ul style="list-style-type: none"> • Host Link • 1:N NT Link • No-protocol mode • Serial PLC Links (master, slave) • Modbus-RTU Easy Master |
| | Serial Option port | | 1 port (Option Board can be mounted only to N30/40/60 and NA20 CPU Units.) |
| | | Mountable Option Boards | <ul style="list-style-type: none"> • One RS-232C port: CP1W-CIF01 • One RS-422A/485 port (not isolated): CP1W-CIF11 • One RS-422A/485 port (isolated): CP1W-CIF12 • One Ethernet port: CP1W-CIF41 |
| | | Communications method | Option Board cannot be mounted. |
| | | synchronization | Depends on Option Board. |
| | | Baud rate | 1.2, 2.4, 4.8, 9.6, 19.2, 38.4, 57.6, or 115.2 kbps |
| | | Compatible protocols | <ul style="list-style-type: none"> • Host Link • 1:N NT Link • No-protocol mode • Serial PLC Links (master, slave) • Modbus-RTU Easy Master |
| Number of tasks | | 17 <ul style="list-style-type: none"> • One cyclic execution task • One scheduled interrupt task (always interrupt task 1) • Six input interrupt tasks (interrupt tasks 2 to 7) • Sixteen high-speed counter interrupt tasks (interrupt tasks 1 to 16) | |
| Maximum subroutine number | | 128 | |
| Maximum jump number | | 128 | |
| Scheduled interrupt tasks | | 1 interrupt task | |
| Clock | | Clock function not included. The time of error occurrence displays 01-01-01 01:01:01 Sunday | Included. Accuracy (monthly deviation): -4.5 min to -0.5 min at ambient temperature of 55°C, -2.0 min to +2.0 min at ambient temperature of 25°C, -2.5 min to +1.5 min at ambient temperature of 0°C |
| Memory backup | Built-in EEPROM | | Ladder programs and parameters are automatically saved to built-in EEPROM A section of the Data Memory Area can be saved to the built-in EEPROM. |
| | Battery backup With CP1W-BAT01 Battery (Sold separately) | | Battery cannot be mounted. CP1W-BAT01 can be used. Maximum battery service life: 5 years Backup Time Guaranteed value (ambient temperature: 55°C): 13,000 hours (approx. 1.5 years) Effective value (ambient temperature: 25°C): 43,000 hours (approx. 5 years) |
| CIO Area | Input Bits | | 1,600 bits (100 words): CIO 0.00 to CIO 99.15 (CIO 00 to CIO 99) |
| | Output Bits | | 1,600 bits (100 words): CIO 100.00 to CIO 199.15 (CIO 100 to CIO 199) |
| | Serial PLC Link Words | | 1,440 bits (90 words): CIO 200.00 to CIO 289.15 (words CIO 200 to CIO 289) |
| Work Area (W) | | 1,600 bits (100 words): W0.00 to W99.15 (W0 to W99) | |
| Holding Area (H) | | 800 bits (50 words): H0.00 to H49.15 (H0 to H49) Bits in this area maintain their ON/OFF status when operating mode is changed. | |
| Auxiliary Area (A) | | Read-only: 7,168 bits (448 words) A0 to A447 Read/write: 4,896 bits (306 words) in words A448 to A753 | |
| Temporary Relay Area (TR) (TR Area) | | 16 bits: TR0 to TR15 | |
| Timer Area (T) | | 256 timer numbers (T0 to T255 (separate from counters)) | |
| Counter Area (C) | | 256 counter numbers (C0 to C255 (separate from timers)) | |
| Data Memory Area (D) | | 2 Kwords: D0 to D2047 Of these, 1,500 words can be saved to the backup memory (built-in EEPROM) using settings in the Auxiliary Area. | 8 Kwords: D0 to D8191 Of these, 7,000 words can be saved to the backup memory (built-in EEPROM) using settings in the Auxiliary Area |
| Operating modes | | PROGRAM mode: Program execution is stopped. Preparations can be executed prior to program execution in this mode. MONITOR mode: Programs are executed. Some operations, such as online editing, and changes to present values in I/O memory, are enabled in this mode. RUN mode: Programs are executed. This is the normal operating mode. | |

Function Specifications


| Function | | | | Function description | |
|---|---|---|---|--|--|
| Cycle time management | Minimum cycle time | | | Makes the cycle time consistent. | |
| | Monitoring the cycle time | | | Monitors the cycle time. | |
| CPU Unit built-in functions | Inputs | High-speed counter inputs | High-speed pulse inputs | | High-speed pulses from devices such as a rotary encoder are counted. The counted values are stored in the Auxiliary Area. Interrupt tasks can be executed when target is reached or by range comparison. |
| | | | Input pulse frequency measurement | | The frequency of pulses input by the PRV instruction is measured. |
| | | Interrupt inputs | | | Relevant interrupt tasks are executed during the cycle when the CPU Unit built-in inputs turn ON or turn OFF. |
| | | Quick-response inputs | | | Inputs can be read without being affected by cycle time. Use the quick-response inputs to read signals shorter than the cycle time. |
| | | Normal inputs | I/O refreshing | Cyclic refreshing | The CPU Unit's built-in I/O are cyclically refreshed. |
| | | | | Immediate refreshing | I/O refreshing by immediate refreshing instructions |
| | | | Input response times | | |
| | | Outputs | Pulse outputs (Models with transistor outputs only) | Pulse control | |
| | Origin positioning | | | Origin searches and origin returns | |
| | PWM outputs (Models with transistor outputs only) | | | Pulses for which the duty ratio (ratio between ON time and OFF time during one pulse cycle) can be set are output. | |
| | Normal outputs | | Load OFF function | | All of the outputs on the CPU Unit's I/O can be turned OFF when an error occurs in RUN or MONITOR mode. |
| | Built-in analog | Analog input | | | Convert analog signal into digital value range from 0 to 6,000. |
| | | Analog output | | | Convert digital value range from 0 to 6,000 into analog signal. |
| | Expansion I/O Units and Expansion Units | Functions supported by both Expansion I/O Unit and Expansion Unit | I/O refreshing | Cyclic refreshing | |
| Refreshing by IORF | | | | I/O refreshing by IORF instruction | |
| | | Load OFF function | | | All of the outputs on Expansion I/O Units and Expansion Units are turned OFF (0000 hex) when an error occurs in RUN or MONITOR mode. |
| | | Expansion I/O Units | Input response times | | |
| | Expansion Units | Unit error detection | | | Errors in Expansion Units are detected. The CPU Unit is notified that the Expansion Unit stopped due to an error. |
| | Memory management functions | Holding I/O memory when changing operating modes | | | The status of I/O memory can be held when the operating mode is changed. The forced-set/reset status can be held when the operating mode is changed. |
| Automatic backup to the backup memory (built-in EEPROM) | | | Automatic backup of ladder programs and parameter area to the backup memory (built-in EEPROM) | | |
| Communications | Peripheral USB port | Peripheral bus (toolbus) | | | For communications with programming device (CX-Programmer). |
| | Serial port (N/NA-type only) | | | | -- |
| | | Host Link (SYSWAY) communications | | | Host Link commands can be sent from a PT or a computer to read/write I/O memory, and perform other operations for PLC. |
| | | No-protocol communications | | | I/O instructions for communications ports (TXD/RXD instructions) can be used for data transfer with peripheral devices such as bar code readers. |
| | | NT Link communications | | | I/O memory in the PLC can be allocated and directly linked to various PT functions, including status control areas, status notification areas, touch switches, lamps, memory tables, and other objects. |
| | | Serial PLC Links | | | Up to ten words per Unit can be shared by up to nine CPU Units, including one Polling Unit and eight Polled Units. Note: Programmable Terminal (PT) cannot be connected. |
| | | Modbus-RTU Easy Master function | | | Modbus-RTU commands are sent by the Modbus-RTU Master function. Modbus slaves, such as inverters, can be easily controlled with serial communications. |
| Interrupt | Scheduled interrupts | | | Tasks can be executed at a specified interval (1.0 ms min., Unit: 0.1 ms). | |
| | Interrupt inputs | | | Interrupt tasks are processed when the built-in input turns ON or OFF. | |
| | High-speed counter interrupts | | | This function counts input pulses with the CPU Unit's built-in high-speed counter and executes an interrupt task when the count reaches the preset value or falls within a preset range (target value or zone comparison). | |

| Function | | | Function description | |
|--|---|--|--|---|
| Power supply management | Memory protection | | Holding Area data, DM Area data, Counter Completion Flags, and counter present values are held even when power is turned OFF. This function can be used only with an N/NA-type CPU Unit and only when the Battery Set (sold separately) is mounted. | |
| | Number of power interruptions counter | | The number of times power has been interrupted is counted. | |
| Debugging | Online editing | | The program can be changed during operation in MONITOR mode or PROGRAM mode. | |
| | Force-set/reset | | Specified bits can be set or reset. | |
| | Differentiate monitoring | | ON/OFF changes in specified bits can be monitored. | |
| | Storing the stop position at errors | | The location and task number where execution stopped for a program error is recorded. | |
| | Program check | | The programs can be checked for items such as no END instruction and FALS/FAL errors at startup. | |
| Self-diagnosis and restoration | Error Log | | Details and the time of occurrence of error codes predefined by the CPU Unit are stored. | |
| | CPU error detection | | CPU Unit WDT errors are detected. | |
| | User-defined failure diagnosis | | Errors can be generated for user-specified conditions: Non-fatal errors (FAL) and fatal errors (FALS). | |
| | Load OFF function | | The built-in outputs, Expansion I/O Unit outputs, and Expansion Unit outputs are turned OFF. | |
| | Non-fatal error detection | System FAL error detection (User-defined non-fatal error) | | This function generates a non-fatal (FAL) error when the user-defined conditions are met in program. |
| | | Backup memory error detection | | This function detects when data in the backup memory (built-in EEPROM) that stores the ladder program is corrupted. |
| | | PLC Setup error detection | | This function detects setting errors in the PLC Setup. |
| | | Option Board errors | | This function detects when the Option Board is malfunctioning or disconnected. |
| | | Battery error detection (N/NA-type CPU Units only) | | This function detects when the battery voltage is low or the battery is disconnected. Note: This function is valid only when a battery is mounted and the Do not detect battery error Check Box is cleared in the PLC Setup. |
| | | Built-in analog error | | This function detects when a built-in analog I/O error occurs and stops the operation of built-in analog I/O. |
| | Fatal Error Detection | Memory error detection | | This function detects errors that occur in memory of the CPU Unit. |
| | | I/O bus error detection | | This function detects errors that occur during data transfer between the CPU Unit and another Unit. |
| | | Too Many I/O Points Error Detection | | This function detects when more than the maximum number of CP1W Expansion I/O Units and Expansion Units are connected to the PLC. |
| | | Program error detection | | This function detects when there is an error in the program. See the following for details. |
| | | Instruction processing error detection | | This function detects an error when the given data value is invalid when executing an instruction, or execution of instruction between tasks was attempted. |
| | | Indirect DM addressing BCD error | | This function detects an error when an indirect DM address in BCD mode is not BCD. |
| | | Illegal area access error detection | | This function detects an error when an attempt is made to access an illegal area with an instruction operand. |
| No END error detection | | This function detects an error when there is no END instruction at the end of the program. | | |
| Task error detection | | The execution condition for an interrupt task was met but there is no interrupt task with the specified number. | | |
| overflow error detection | | This function detects an error when too many differentiated instructions are entered or deleted during online editing (131,072 times or more). | | |
| Invalid instruction error detection | | This function detects an error when an attempt is made to execute an instruction that is not defined in the system. | | |
| User program area overflow error detection | | This function detects an error when instruction data is stored after the last address in user program area. | | |
| Cycle time exceeded error detection | | This function monitors the cycle time (10 to 1,000 ms) and stops the operation when the set value is exceeded. | | |
| System FALS error detection (user-defined fatal error) | | This function generates a fatal (FALS) error when the user-defined conditions are met in program. | | |
| Maintenance | Automatic online connection via network | | This function enables automatically connecting to the PLC online when the CX-Programmer is directly connected by a serial connection (peripheral USB port or serial port). | |
| Security functions | Read protection using password | | This function protects user memory. Read protection: Set a password using the CX-Programmer. Overwrite protection is not provided. | |
| | Write protection from FINS commands | | This function prohibits writing by using FINS commands sent over the network. | |

Internal Memory in the CPU Units

CPU Unit Memory Backup Structure

The internal memory in the CPU Unit consists of built-in RAM and built-in EEPROM. The built-in RAM is used as execution memory and the built-in EEPROM is used as backup memory.




●Precautions for Correct Use

Create a system and write the ladder programs so that problems will not occur in the system if the data in these area may be unstable.


- Data in areas such as the DM area (D), Holding Area (H), the Counter Present Values (C) and the status of Counter Completion Flags (C), which is retained by the battery, may be unstable when the power supply is turned off (Except for the DM area that are retained by the built-in EEPROM using the Auxilliary Area bit.)
- The error log, and clock data (N/NA-type CPU Unit only) in the Auxiliary Area will become unstable. Other words and bits in the Auxiliary Area will be cleared to their default values.

The built-in capacitor's backup time varies with the ambient temperature as shown in the following graph.



I/O Memory Areas

Data can be read and written to I/O memory from the ladder programs. I/O memory consists of an area for I/O with external devices, user areas, and system areas.




I/O Memory Areas

| Name | | No. of bits | Word addresses | Remarks |
|----------------------|--------------------------|------------------------|--------------------|---|
| CIO Area | Input Bits | 1,600 bits (100 words) | CIO 0 to CIO 99 | For NA-type, CIO90, CIO91 is occupied by analog input 0, 1. |
| | Output Bits | 1,600 bits (100 words) | CIO 100 to CIO 199 | For NA-type, CIO190 is occupied by analog output 0. |
| | Serial PLC Link Words | 1,440 bits (90 words) | CIO 200 to CIO 289 | -- |
| Work Area (W) | | 1,600 bits (100 words) | W0 to W99 | -- |
| Holding Area (H) | | 800 bits (50 words) | H0 to H49 | Data in this area is retained during power interruptions if a Battery Set (sold separately) is mounted to an N/NA-type CPU Unit. |
| Data Memory Area (D) | E-type CPU Unit | 2K words | D0 to D2047 | Data in specified words of the DM Area can be retained in the built-in EEPROM in the backup memory by using a bit in the Auxiliary Area. Applicable words: D0 to D1499 (One word can be specified at a time.) |
| | N/NA-type CPU Unit | 8K words | D0 to D8191 | Data in specified words of the DM Area can be retained in the built-in EEPROM in the backup memory by using a bit in the Auxiliary Area. Applicable words: D0 to D6999 (One word can be specified at a time.) |
| Timer Area (T) | Present values | 256 | T0 to T255 | -- |
| | Timer Completion Flags | 256 | | -- |
| Counter Area (C) | Present values | 256 | C0 to C255 | Data in this area is retained during power interruptions if a Battery Set (sold separately) is mounted to an N/NA-type CPU Unit. |
| | Counter Completion Flags | 256 | | -- |
| Auxiliary Area (A) | Read only | 7168 bits (448 words) | A0 to A447 | Data in this area is retained during power interruptions if a Battery Set (sold separately) is mounted to an N/NA-type CPU Unit. |
| | Read-write | 4,896 bits (306 words) | A448 to A753 | |

Backing Up and Restoring DM Area Data

The contents of the DM Area (D) will become unstable if the power supply is interrupted for longer than the backup time of the built-in capacitor (50 hours for an E-type CPU Unit, 40 hours for an N/NA-type CPU Unit without a Battery).

The contents of the specified words in the DM Area data can be backed up from RAM to the built-in EEPROM backup memory during operation by turning ON a bit in the Auxiliary Area. The number of DM Area words to back up is specified in the Number of CH of DM for backup Box in the PLC Setup. If the Restore D0- from backup memory Check Box is selected in the PLC Setup, the backup data will automatically be restored to RAM when the power is turned back ON so that data is not lost even if power is interrupted.



Conditions for Executing Backup

Specified words starting from D0 in the RAM can be saved to the built-in EEPROM backup memory by turning ON A751.15. (These words are called the DM backup words and the data is called the DM backup data.)

A751.15 (DM Backup Save Start Bit) can be used in any operating mode (RUN, MONITOR, or PROGRAM mode).

Words That Can Be Backed Up

- E-type CP1E CPU Units: D0 to D1499
- N/NA-type CP1E CPU Units: D0 to D6999


Number of Words To Back Up

The number of words to back up starting from D0 is set in the *Number of CH of DM for backup* Box in the *Startup Data Read Area* in the PLC Setup.

Restoring DM Backup Data to RAM When Power Is Turned ON

The DM backup data can be restored to RAM when power is turned ON by selecting the *Restore D0- from backup memory* Check Box in the *Startup Data Read Area* in the PLC Setup.

The DM backup data will be read from the backup memory even if the *Clear retained memory area (HR/DM/CNT)* Check Box is selected in the PLC Setup.




Built-in Inputs


Terminal Arrangements

●Input Terminal Arrangement for CPU Unit with 10 I/O Points

AC power supply models




DC power supply models




●Input Terminal Arrangement for CPU Unit with 14 I/O Points

AC power supply models




DC power supply models




●Input Terminal Arrangement for CPU Unit with 20 I/O Points

AC power supply models




DC power supply models




●Input Terminal Arrangement for CPU Unit with 30 I/O Points

AC power supply models



DC power supply models



●Input Terminal Arrangement for CPU Unit with 40 I/O Points

AC power supply models



| CIO 0 | | | | | | | | | | CIO 1 | | | | | |
|-------|------|-----|----|----|----|----|----|----|--|-------|----|----|----|----|----|
| L1 | L2/N | COM | 01 | 03 | 05 | 07 | 09 | 11 | | 01 | 03 | 05 | 07 | 09 | 11 |
| | | | 00 | 02 | 04 | 06 | 08 | 10 | | 00 | 02 | 04 | 06 | 08 | 10 |

DC power supply models


| CIO 0 | | | | | | | | | | CIO 1 | | | | | |
|-------|---|-----|----|----|----|----|----|----|--|-------|----|----|----|----|----|
| + | - | COM | 01 | 03 | 05 | 07 | 09 | 11 | | 01 | 03 | 05 | 07 | 09 | 11 |
| NC | | | 00 | 02 | 04 | 06 | 08 | 10 | | 00 | 02 | 04 | 06 | 08 | 10 |

●Input Terminal Arrangement for CPU Unit with 60 I/O Points

AC power supply models

| CIO 0 | | | | | | | | | | CIO 1 | | | | | | CIO 2 | | | | | | |
|---|---|-----|----|----|----|----|----|----|--|-------|----|----|----|----|----|-------|----|----|----|----|----|----|
| L1 | L2/N | COM | 01 | 03 | 05 | 07 | 09 | 11 | | 01 | 03 | 05 | 07 | 09 | 11 | | 01 | 03 | 05 | 07 | 09 | 11 |
|  |  | | 00 | 02 | 04 | 06 | 08 | 10 | | 00 | 02 | 04 | 06 | 08 | 10 | | 00 | 02 | 04 | 06 | 08 | 10 |

DC power supply models

| CIO 0 | | | | | | | | | CIO 1 | | | | | | | CIO 2 | | | | | | |
|-------|---|-----|----|----|----|----|----|----|-------|----|----|----|----|----|----|-------|----|----|----|----|--|--|
| + | - | COM | 01 | 03 | 05 | 07 | 09 | 11 | 01 | 03 | 05 | 07 | 09 | 11 | 01 | 03 | 05 | 07 | 09 | 11 | | |
| NC |  | 00 | 02 | 04 | 06 | 08 | 10 | 00 | 02 | 04 | 06 | 08 | 10 | 00 | 02 | 04 | 06 | 08 | 10 | | | |

●Input Terminal Arrangement for CPU Unit with 20 I/O Points and Built-in Analog

AC power supply models

| CIO 0 | | | | | | | | | | CIO 90 | | CIO 91 | |
|-------|------|-----|----|----|----|----|----|----|--|--------|------|--------|------|
| L1 | L2/N | COM | 01 | 03 | 05 | 07 | 09 | 11 | | I IN0 | AG | I IN1 | |
| | | | 00 | 02 | 04 | 06 | 08 | 10 | | VIN0 | COM0 | VIN1 | COM1 |

DC power supply models

| CIO 0 | | | | | | | | | | CIO 90 | | CIO 91 | |
|-------|---|-----|----|----|----|----|----|----|--|--------|------|--------|------|
| + | - | COM | 01 | 03 | 05 | 07 | 09 | 11 | | I IN0 | AG | I IN1 | |
| NC | | | 00 | 02 | 04 | 06 | 08 | 10 | | VIN0 | COM0 | VIN1 | COM1 |

Allocating Built-in Inputs to Functions

Input terminals are allocated functions by setting parameters in the PLC Setup. Set the PLC Setup so that each terminal is used for only one function.

| CPU Unit with I/O Points | Input terminal block | | Settings in PLC Setup | | | | | | | |
|--------------------------|----------------------|-----------------|--|-------------------|------------------------|--|--|-----------------------------|---|--|
| | | | Interrupt input setting on Built-in Input Tab Page | | | High-speed counter 0 to 3 setting on Built-in Input Tab Page | | | Origin search settings on Pulse Output 0/1 Tab Page | |
| | Terminal block label | Terminal number | Normal | Interrupt | Quick | Single-phase (increment pulse input) | Two-phase (differential phase x4 or up/down) | Two-phase (pulse/direction) | CPU Unit with 20 to 60 points | CPU Unit with 14 I/O points |
| 10 | CIO 0 | 00 | Normal input 0 | -- | -- | Counter 0, increment input | Counter 0, phase A or up input | Counter 0, pulse input | -- | -- |
| | | 01 | Normal input 1 | -- | -- | Counter 1, increment input | Counter 0, phase B or down input | Counter 1, pulse input | -- | -- |
| | | 02 | Normal input 2 | Interrupt input 2 | Quick-response input 2 | Counter 2, increment input | Counter 1, phase A or up input | Counter 0, direction | -- | -- |
| | | 03 | Normal input 3 | Interrupt input 3 | Quick-response input 3 | -- | Counter 1, phase B or down input | Counter 1, direction | -- | Pulse 0, Origin proximity input signal |
| | | 04 | Normal input 4 | Interrupt input 4 | Quick-response input 4 | Counter 3, increment input | Counter 0, phase Z or reset input | Counter 0, reset input | -- | -- |
| | | 05 | Normal input 5 | Interrupt input 5 | Quick-response input 5 | Counter 4, increment input | Counter 1, phase Z or reset input | Counter 1, reset input | -- | Pulse 1, Origin proximity input signal |
| | | 06 | Normal input 6 | Interrupt input 6 | Quick-response input 6 | Counter 5, increment input | -- | -- | Pulse 0: Origin input signal | Pulse 0, Origin input signal |
| | | 07 | Normal input 7 | Interrupt input 7 | Quick-response input 7 | -- | -- | -- | Pulse 1: Origin input signal | Pulse 1, Origin input signal |
| | | 08 | Normal input 8 | -- | -- | -- | -- | -- | -- | -- |
| | | 09 | Normal input 9 | -- | -- | -- | -- | -- | -- | -- |
| | | 10 | Normal input 10 | -- | -- | -- | -- | -- | Pulse 0: Origin proximity input signal | -- |
| | | 11 | Normal input 11 | -- | -- | -- | -- | -- | Pulse 1: Origin proximity input signal | -- |
| 30 | CIO 1 | 00 to 05 | Normal input 12 to 17 | -- | -- | -- | -- | -- | -- | -- |
| 40 | | 06 to 11 | Normal input 18 to 23 | -- | -- | -- | -- | -- | -- | -- |
| 60 | CIO 2 | 00 to 11 | Normal input 24 to 35 | -- | -- | -- | -- | -- | -- | -- |

These functions are supported only by N/NA-type CPU Units with transistor outputs.


Built-in Outputs

Terminal Arrangements

●Output Terminal Arrangement for CPU Unit with 10 I/O Points

AC power supply model


DC power supply model



●Output Terminal Arrangement for CPU Unit with 14 I/O Points

AC power supply model


DC power supply model



●Output Terminal Arrangement for CPU Unit with 20 I/O Points

AC power supply model



DC power supply model



●Output Terminal Arrangement for CPU Unit with 30 I/O Points


AC power supply model

DC power supply model




●Output Terminal Arrangement for CPU Unit with 40 I/O Points

AC power supply model




DC power supply model




●Output Terminal Arrangement for CPU Unit with 60 I/O Points

AC power supply model





DC power supply model



●Output Terminal Arrangement for CPU Unit with 20 I/O Points and Built-in Analog

AC power supply model

DC power supply model



Allocating Built-in Output Terminals to Functions

Output terminals are allocated functions by setting parameters in the PLC Setup. Set the PLC Setup so that each terminal is used for only one function.

| CPU Unit with I/O points | Output terminal block | | Other than those shown right | When a pulse output instruction (SPED, ACC, PLS2, or ORG) is executed | Setting in PLC Setup Origin search setting on Pulse Output 0/1 Tab Page | When the PWM instruction is executed |
|--|-----------------------|-----------------|------------------------------|---|--|--------------------------------------|
| | Terminal block label | Terminal number | Normal output | Fixed duty ratio pulse output | | Variable duty ratio pulse output |
| | | | | Pulse + direction | Use | PWM output |
| <div> <div>10</div> <div>14</div> <div>20</div> <div>30</div> <div>40</div> <div>60</div> </div> | CIO 100 | 00 | Normal output 0 | Pulse output 0 (pulse) | -- | -- |
| | | 01 | Normal output 1 | Pulse output 1 (pulse) | -- | PWM output 0 |
| | | 02 | Normal output 2 | Pulse output 0 (direction) | -- | -- |
| | | 03 | Normal output 3 | Pulse output 1 (direction) | -- | -- |
| | | 04 | Normal output 4 | -- | Pulse 0: Error counter reset output | -- |
| | | 05 | Normal output 5 | -- | Pulse 1: Error counter reset output | -- |
| | | 06 | Normal output 6 | -- | -- | -- |
| | | 07 | Normal output 7 | -- | -- | -- |
| | CIO 101 | 00 to 03 | Normal output 8 to 11 | -- | -- | -- |
| | | 04 to 07 | Normal output 12 to 15 | -- | -- | -- |
| | CIO 102 | 00 to 07 | Normal output 16 to 23 | -- | -- | -- |

These functions are supported only by N/NA-type CPU Units with transistor outputs.

I/O Specifications for CPU Units



Input Specifications

| Item | Specification | | |
|-----------------------|--|---|--|
| Input type | High-speed counter inputs or Normal Inputs | High-speed counter inputs, interrupt input, quick-response inputs, or Normal Inputs | Normal inputs |
| Input bits | CIO 0.00 to CIO 0.01 | CIO 0.02 to CIO 0.07 *1 | CIO 0.08 to CIO 0.11, CIO 1.00 to CIO 1.11 and CIO 2.00 to CIO 2.11 *1 |
| Input voltage | 24 VDC, +10%, -15% | | |
| Applicable sensors | 2-wire and 3-wire sensors | | |
| Input impedance | 3.3 k Ω | 3.3 k Ω | 4.8 k Ω |
| Input current | 7.5 mA typical | 7.5 mA typical | 5 mA typical |
| ON voltage/current | 3 mA min. at 17.0 VDC min. | 3 mA min. at 17.0 VDC min. | 3 mA min. at 14.4 VDC min. |
| OFF voltage/current | 1 mA max. at 5.0 VDC max. | 1 mA max. at 5.0 VDC max. | 1 mA max. at 5.0 VDC max. |
| ON response time *2 | E-type CPU Unit: 50 μ s min. N/NA-type CPU Unit: 2.5 μ s min. | 50 μ s max. | 1 ms max. |
| OFF response time *2 | E-type CPU Unit: 50 μ s min. N/NA-type CPU Unit: 2.5 μ s min. | 50 μ s max. | 1 ms max. |
| Circuit configuration | E-type CPU Unit | | N/NA-type CPU Unit |
| | Input 0.00 to 0.07 | | Input 0.00 to 0.01 |
| | Input 0.08 to 0.11, 1.00 to 1.11 | | Input 0.02 to 0.07 |
| | | | Inputs CIO 0.08 to CIO 0.11, CIO 1.00 to CIO 1.11 and CIO 2.00 to CIO 2.11 |



* 1 The bits that can be used depend on the model of CPU Unit.

* 2 The response time is the delay caused by hardware. The delay set in the PLC Setup (0 to 32 ms, default: 8 ms) for a normal input must be added to this value.

Pulse plus direction input mode,
Increment mode
Up/down input mode




Differential phase mode




Output Specifications

●Output Specifications for Relay Outputs

| Item | | | Specification |
|----------------------------|------------|----------------|---|
| Maximum switching capacity | | | 250 VAC/2 A ($\cos\phi = 1$) 2 A, 24 VDC (4 A/common) |
| Minimum switching capacity | | | 5 VDC, 10 mA |
| Service life of relay | Electrical | Resistive load | 200,000 operations (24 VDC) |
| | | Inductive load | 70,000 operations (250 VAC, $\cos\phi = 0.4$) |
| | Mechanical | | 20,000,000 operations |
| ON delay | | | 15 ms max. |
| OFF response time | | | 15 ms max. |
| Circuit configuration | | |  |


Estimating the Service Life of Relays

Under normal conditions, the service life of output contacts is as shown above. The service life of relays is as shown in the following diagram as a guideline



Relationship between Continuous Simultaneous ON Rate and Ambient Temperature





There are restrictions on the power supply voltage and output load current imposed by the ambient temperature. Make sure that the power supply voltage and output load current are within the following ranges.



Note: The above restrictions apply to the relay output load current from the CPU Unit even if Expansion I/O Units are not connected.

●Output Specifications for Transistor Outputs (Sinking or Sourcing)

Normal Outputs


| Item | Specification | |
|----------------------------|---|--|
| | CIO 100.00 and CIO 100.01 | CIO 100.02 to CIO 100.07, CIO 101.00 to CIO 101.07 and CIO 102.00 to CIO 102.07 *2 |
| Maximum switching capacity | 0.3 A/output, 0.9 A/common *1 4.5 to 30 VDC CP1E-E10D□-□: 0.9 A/Unit CP1E-N14D□-□: 1.5 A/Unit CP1E-N40D□-□: 3.6 A/Unit CP1E-N60D□-□: 5.4 A/Unit | CP1E-N20D□-□: 1.8 A/Unit CP1E-N30D□-□: 2.7 A/Unit CP1E-NA20D□-□: 1.8 A/Unit |
| Minimum switching capacity | 1 mA 4.5 to 30 VDC | |
| Leakage current | 0.1mA max. | |
| Residual voltage | E-type CPU Unit: 1.5 V max. N/NA-type CPU Unit: 0.6 V max. | 1.5V max. |
| ON response time | 0.1 ms max. | 0.1 ms max. |
| OFF response time | E-type CPU Unit: 1 ms max. N/NA-type CPU Unit: 0.1 ms max. | 1 ms max. |
| Fuse | Not provided. | |
| Circuit configuration | <p>N/NA-type CPU Unit: Normal outputs CIO 100.00 to CIO 100.01 (sinking)</p>  <p>N/NA-type CPU Unit: Normal outputs CIO 100.00 to CIO 100.01 (sourcing)</p>  | <p>E-type CPU Unit: Normal outputs CIO 100.00 to CIO 100.03 (sinking) N/NA-type CPU Unit: Normal outputs CIO 100.02 to CIO 102.07 (sinking)</p>  <p>E-type CPU Unit: Normal outputs CIO 100.01 to CIO 100.03 (sourcing) N/NA-type CPU Unit: Normal outputs CIO 100.02 to CIO 102.07 (sourcing)</p>  |

Note: Do not connect a load to an output terminal or apply a voltage in excess of the maximum switching capacity.

* 1 Also do not exceed 0.9 A for the total for CIO 100.00 to CIO 100.03. (CIO 100.00 to CIO 100.03 is different common.)

* 2 The bits that can be used depend on the model of CPU Unit.

Pulse Outputs (CIO 100.00 and CIO 100.01)


| Item | Specification |
|----------------------------|--|
| Maximum switching capacity | 100 mA/4.5 to 26.4 VDC |
| Minimum switching capacity | 7 mA/4.5 to 26.4 VDC |
| Maximum output frequency | 100 kHz |
| Output waveform |  |

Note: 1. The load for the above values is assumed to be the resistance load, and does not take into account the impedance for the connecting cable to the load.

2. Due to distortions in pulse waveforms resulting from connecting cable impedance, the pulse widths in actual operation may be smaller than the values shown above.

3. The OFF and ON refer to the output transistor. The output transistor is ON at level "L".

PWM Output (CIO 100.01)

| Item | Specification |
|----------------------------|---|
| Maximum switching capacity | 30 mA/4.5 to 26.4 VDC |
| Maximum output frequency | 32 kHz |
| PWM output accuracy | For ON duty +1%, .0%: 10 kHz output For ON duty +5%, .0%: 0 to 32 kHz output |
| Output waveform |  |

Note: The OFF and ON refer to the output transistor. The output transistor is ON at level "L".

Built-in Analog I/O (NA-type CPU Units)

●Analog Input Specifications

| Item | | Voltage input | Current input |
|---------------------------------|--------------|---|--------------------------|
| Number of inputs | | 2 inputs (Allocated 2 words: CIO 90 to CIO 91.) | |
| Input signal range | | 0 to 5 V, 1 to 5 V, 0 to 10 V, or -10 to 10 V | 0 to 20 mA or 4 to 20 mA |
| Max. rated input | | ±15 V | ±30 mA |
| External input impedance | | 1 MΩ min. | Approx. 250Ω |
| Resolution | | 1/6000 | |
| Overall accuracy | At 25°C | ±0.3% full scale | ±0.4% full scale |
| | 0 to 55°C | ±0.6% full scale | ±0.8% full scale |
| A/D conversion data | -10 to +10 V | F448 to 0BB8 hex FS | |
| | Other ranges | 0000 to 1770 hex FS | |
| Averaging function | | Supported (Set for individual inputs in the PLC Setup.) | |
| Open-circuit detection function | | Supported (Value when disconnected: 8000 hex) | |

●Analog Output Specifications

| Item | | Voltage output | Current output |
|---|--------------|---|--------------------------|
| Number of outputs | | 1 output (Allocated 1 word: CIO 190.) | |
| Output signal range | | 0 to 5 V, 1 to 5 V, 0 to 10 V, or -10 to 10 V | 0 to 20 mA or 4 to 20 mA |
| Allowable external output load resistance | | 1 kΩ min. | 600Ω max. |
| External input impedance | | 0.5Ωmax. | --- |
| Resolution | | 1/6000 | |
| Overall accuracy | At 25°C | ±0.4% full scale * | |
| | 0 to 55°C | ±0.8% full scale * | |
| D/A conversion data | -10 to +10 V | F448 to 0BB8 hex FS | |
| | Other ranges | 0000 to 1770 hex FS | |

* In 0 to 20 mA mode, accuracy cannot be ensured at 0.2 mA or less.

●Shared I/O Specifications


| Item | Specification |
|------------------|--|
| Conversion time | 2 ms/point (6 ms total for 2 analog inputs and 1 analog output.) |
| Isolation method | Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals. |

Specifications of Expansion I/O Units and Expansion Units


Expandable CPU Units

- Expansion I/O Units and Expansion Units cannot be connected to E10/14/20 or N14/20 CPU Units.
- A total of up to three Expansion I/O Units and Expansion Units can be connected to an E30/40, N30/40/60 or NA20 CPU Unit.

●CP1E E10/14/20 or N14/20 CPU Unit



●CP1E E30/40, N30/40/60 or NA20 CPU Unit



Connection Methods

Connection cables for the Expansion I/O Units and Expansion Units are used to connect the Units. The length can be extended by using a CP1W-CN811 I/O Connection Cable (length: 800 m).

Maximum Number of I/O Points for an Expanded System

| CPU Unit | Built-in I/O on CPU Unit | | | Built-in Analog | | Total number of Expansion I/O Units and Expansion Units that can be connected | Number of inputs: 24 Number of outputs: 16 Total number of I/O points when three CP1W-40ED□ Expansion I/O Units are connected | | |
|---------------|--------------------------|------------------|-------------------|-----------------|------|---|---|------------------|-------------------|
| | Total | Number of inputs | Number of outputs | AD | DA | | Total | Number of inputs | Number of outputs |
| CP1E-E10D□-□ | 10 | 6 | 4 | None | None | Not possible. | 10 | 6 | 4 |
| CP1E-□14D□-□ | 14 | 8 | 6 | | | | 14 | 8 | 6 |
| CP1E-□20D□-□ | 20 | 12 | 8 | | | | 20 | 12 | 8 |
| CP1E-□30D□-□ | 30 | 18 | 12 | | | 3 Units maximum | 150 | 90 | 60 |
| CP1E-□40D□-□ | 40 | 24 | 16 | | | | 160 | 96 | 64 |
| CP1E-N60D□-□ | 60 | 36 | 24 | | | | 180 | 108 | 72 |
| CP1E-NA20D□-□ | 20 | 12 | 8 | 2 | 1 | | 140 | 84 | 56 |

Restrictions on External Power Supply Capacity

The following restrictions apply when using the CPU Unit's external power supply.

●AC-power-supply E30/40, N30/40/60 or NA20 CPU Unit

The power supply capacity is restricted for AC-power-supply E30/40, N30/40/60 or NA20 CPU Units. It may not be possible to use the full 300 mA of the external power supply, though a CPU Unit can connect any CP-series Expansion I/O Unit or Expansion Unit.

The entire 300 mA from the external power supply can be used if Expansion Units and Expansion I/O Units are not connected.


Refer to the CP1E CPU Unit Hardware Manual (Cat. No. W479) for details.

●AC-power-supply or DC-power-supply E10/14/20, N14/20 CPU Unit

There is no external power supply on AC-power-supply or DC-power-supply E10/14/20, N14/20 CPU Units.


Specifications of Expansion I/O Units

●Input Specifications (CP1W-40EDR/40EDT/40EDT1/20EDR1/20EDT/20EDT1/8ED)


| Item | Specification |
|-----------------------|---|
| Input voltage | 24 VDC +10%/-15% |
| Input impedance | 4.7 kΩ |
| Input current | 5 mA typical |
| ON voltage | 14.4 VDC min. |
| OFF voltage | 5.0 VDC max. |
| ON delay | 1 ms max. * |
| OFF delay | 1 ms max. * |
| Circuit configuration |  |

Note: Do not apply voltage in excess of the rated voltage to the input terminal.
* The response time is the hardware delay value. The delay set in the PLC Setup (0 to 32 ms, default: 8 ms) must be added to this value. For the CP1W-40EDR/EDT/EDT1, a fixed value of 16 ms must be added.

●Output Specifications
Relay Outputs (CP1W-40EDR/32ER/20EDR1/16ER/8ER)


| Item | | | Specification |
|--------------------------------------|------------|----------------|---|
| Max. switching capacity | | | 2 A, 250 VAC ($\cos\phi = 1$), 2 A, 24 VDC (4 A/common) |
| Min. switching capacity | | | 5 VDC, 10 mA |
| Service life of relay (See note.) | Electrical | Resistive load | 150,000 operations (24 VDC) |
| | | Inductive load | 100,000 operations (240 VAC, $\cos\phi = 0.4$) |
| | Mechanical | | 20,000,000 operations |
| ON delay | | | 15 ms max. |
| OFF delay | | | 15 ms max. |
| Circuit configuration | | | <div><p>Maximum 250 VAC: 2 A 24 VDC: 2 A</p></div> |

Note: 1. Estimating the Service Life of Relays
The service life of output contacts is as shown in the following diagram.




2. Restrictions of CP1W-16ER/32ER


Limit the output load current to satisfy the following derating curve.



3. CP1W-32ER's maximum number of simultaneously ON output points is 24 (75%).
Relation between Number of ON Outputs and Ambient Temperature (CP1W-32ER)




4. According to the ambient temperature, there are restrictions on power supply voltage and output load current for the CPU Units connected with the Expansion I/O Units (CP1W-8ER/16ER/20EDR1/32ER/40EDR). Use the PLC in the range of the power supply voltage and output load current as show below.
The ambient temperature is restricted for the power-supply CPU Units (CP1E-N/NA□□□□-□). Derating curve of the output load current for Expansion I/O Units (CP1W-8ER/16ER/20EDR1/32ER/40EDR).



●Transistor Outputs (Sinking or Sourcing)

| Item | Specification | | | | |
|---|--|---|---|---|---|
| | CP1W-40EDT CP1W-40EDT1 | CP1W-32ET CP1W-32ET1 | CP1W-20EDT CP1W-20EDT1 | CP1W-16ET CP1W-16ET1 | CP1W-8ET CP1W-8ET1 |
| Max. switching capacity *1 | 4.5 to 30 VDC 0.3 A/output 0.9 A/common 3.6 A/Unit | 4.5 to 30 VDC 0.3 A/output 0.9 A/common 7.2 A/Unit | 24 VDC +10%/-5% 0.3 A/output 0.9 A/common 1.8 A/Unit | 4.5 to 30 VDC 0.3 A/output 0.9 A/common 3.6 A/Unit | 4.5 to 30 VDC 0.3 A/output 0.9 A/common 1.8 A/Unit |
| Leakage current | 0.1 mA max. | 0.1 mA max. | 0.1 mA max. | 0.1 mA max. | 0.1 mA max. |
| Residual voltage | 1.5 V max. | 1.5 V max. | 1.5 V max. | 1.5 V max. | 1.5 V max. |
| ON delay | 0.1 ms max. | 0.1 ms max. | 0.1 ms. | 0.1 ms max. | 0.1 ms max. |
| OFF delay | 1 ms max. 24 VDC +10%/-5% 5 to 300 mA | 1 ms max. 24 VDC +10%/-5% 5 to 300 mA | 1 ms max. 24 VDC +10%/-5% 5 to 300 mA | 1 ms max. 24 VDC +10%/-5% 5 to 300 mA | 1 ms max. 24 VDC +10%/-5% 5 to 300 mA |
| Max. number of Simultaneously ON Points of Output | 16 pts (100%) | 24 pts (75%) | 8 pts (100%) | 16 pts (100%) | 8 pts (100%) |
| Fuse *2 | 1 fuse/common | | | | |
| Circuit configuration | <div><div>Sinking Outputs</div></div> <div><div>Sourcing Outputs</div></div> | | | | |

*1 If the ambient temperature is maintained below 50°C, up to 0.9 A/common can be used.



*2 The fuse cannot be replaced by the user. Replace the Unit if the fuse breaks due to an short-circuit or overcurrent.
*3 Do not connect a load to an output terminal or apply a voltage in excess of the maximum switching capacity.

Specifications of Expansion Units

●Analog Input Units

| Model | | CP1W-AD041 | |
|---------------------------------|-----------|--|--------------------------|
| Item | | Voltage Input | Current Input |
| Number of inputs | | 4 inputs (4 words allocated) | |
| Input signal range | | 0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, or -10 to 10 VDC | 0 to 20 mA or 4 to 20 mA |
| Max. rated input | | ±15 V | ±30 mA |
| External input impedance | | 1 MΩ min. | Approx. 250 Ω |
| Resolution | | 1/6000 (full scale) | |
| Overall accuracy | 25°C | 0.3% full scale | 0.4% full scale |
| | 0 to 55°C | 0.6% full scale | 0.8% full scale |
| A/D conversion data | | 16-bit binary (4-digit hexadecimal) Full scale for -10 to 10 V: F448 to 0BB8 Hex Full scale for other ranges: 0000 to 1770 Hex | |
| Averaging function | | Supported (Set in output words n+1 and n+2.) | |
| Open-circuit detection function | | Supported | |
| Conversion time | | 2 ms/point (8 ms/all points) | |
| Isolation method | | Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals. | |
| Current consumption | | 5 VDC: 100 mA max.; 24 VDC: 90 mA max. | |

●Analog Output Units

| Model | | | CP1W-DA021/CP1W-DA041 | |
|-----------------------|---|-----------|--|--------------------------|
| Item | | | Voltage Output | Current Output |
| Analog output section | Number of outputs | | CP1W-DA021: 2 outputs (2 words allocated) CP1W-DA041: 4 outputs (4 words allocated) | |
| | Output signal range | | 1 to 5 VDC, 0 to 10 VDC, or −10 to 10 VDC | 0 to 20 mA or 4 to 20 mA |
| | External output allowable load resistance | | 2 kΩ min. | 350 Ω max. |
| | External output impedance | | 0.5 Ω max. | --- |
| | Resolution | | 1/6000 (full scale) | |
| | Overall accuracy | 25°C | 0.4% full scale | |
| | | 0 to 55°C | 0.8% full scale | |
| | D/A conversion data | | 16-bit binary (4-digit hexadecimal) Full scale for −10 to 10 V: F448 to 0BB8 Hex Full scale for other ranges: 0000 to 1770 Hex | |
| Conversion time | | | CP1W-DA021: 2 ms/point (4 ms/all points) CP1W-DA041: 2 ms/point (8 ms/all points) | |
| Isolation method | | | Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals. | |
| Current consumption | | | CP1W-DA021: 5 VDC: 40 mA max.; 24 VDC: 95 mA max. CP1W-DA041: 5 VDC: 80 mA max.; 24 VDC: 124 mA max. | |

●Analog I/O Units


| Model | | | CP1W-MAD11 | |
|-----------------------|---|-----------|--|--------------------------|
| Item | | | Voltage I/O | Current I/O |
| Analog Input Section | Number of inputs | | 2 inputs (2 words allocated) | |
| | Input signal range | | 0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, or -10 to 10 VDC | 0 to 20 mA or 4 to 20 mA |
| | Max. rated input | | ±15 V | ±30 mA |
| | External input impedance | | 1 MΩ min. | Approx. 250 Ω |
| | Resolution | | 1/6000 (full scale) | |
| | Overall accuracy | 25°C | 0.3% full scale | 0.4% full scale |
| | | 0 to 55°C | 0.6% full scale | 0.8% full scale |
| | A/D conversion data | | 16-bit binary (4-digit hexadecimal) Full scale for -10 to 10 V: F448 to 0BB8 hex Full scale for other ranges: 0000 to 1770 hex | |
| | Averaging function | | Supported (Settable for individual inputs via DIP switch) | |
| | Open-circuit detection function | | Supported | |
| Analog Output Section | Number of outputs | | 1 output (1 word allocated) | |
| | Output signal range | | 1 to 5 VDC, 0 to 10 VDC, or -10 to 10 VDC, | 0 to 20 mA or 4 to 20 mA |
| | Allowable external output load resistance | | 1 kΩ min. | 600 Ω max. |
| | External output impedance | | 0.5 Ω max. | |
| | Resolution | | 1/6000 (full scale) | |
| | Overall accuracy | 25°C | 0.4% full scale | |
| | | 0 to 55°C | 0.8% full scale | |
| | Set data (D/A conversion) | | 16-bit binary (4-digit hexadecimal) Full scale for -10 to 10 V: F448 to 0BB8 hex Full scale for other ranges: 0000 to 1770 hex | |
| Conversion time | | | 2 ms/point (6 ms/all points) | |
| Isolation method | | | Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals. | |
| Current consumption | | | 5 VDC: 83 mA max., 24 VDC: 110 mA max. | |

●Temperature Sensors Units

| Item | CP1W-TS001 | CP1W-TS002 | CP1W-TS101 | CP1W-TS102 |
|----------------------------|---|------------|---|------------|
| Temperature sensors | Thermocouples | | Platinum resistance thermometer | |
| | Switchable between K and J, but same type must be used for all inputs. | | Switchable between Pt100 and JPt100, but same type must be used for all inputs. | |
| Number of inputs | 2 | 4 | 2 | 4 |
| Allocated input words | 2 | 4 | 2 | 4 |
| Accuracy | (The larger of $\pm 0.5\%$ of converted value or $\pm 2^{\circ}\text{C}$) ± 1 digit max. * | | (The larger of $\pm 0.5\%$ of converted value or $\pm 1^{\circ}\text{C}$) ± 1 digit max. | |
| Conversion time | 250 ms for 2 or 4 input points | | | |
| Converted temperature data | 16-bit binary data (4-digit hexadecimal) | | | |
| Isolation | Photocouplers between all temperature input signals | | | |
| Current consumption | 5 VDC: 40 mA max., 24 VDC: 59 mA max. | | 5 VDC: 54 mA max., 24 VDC: 73 mA max. | |

* Accuracy for a K-type sensor at -100°C or less is ±4°C ±1 digit max.

The rotary switch is used to set the temperature range.

| Setting | | CP1W-TS001/TS002 | | | CP1W-TS101/TS102 | | |
|--|--------|------------------|----------------|---------------|------------------|-----------------|-------------------|
| | | Input type | Range (°C) | Range (°F) | Input type | Range (°C) | Range (°F) |
|  | 0 | K | -200 to 1,300 | -300 to 2,300 | Pt100 | -200.0 to 650.0 | -300.0 to 1,200.0 |
| | 1 | | 0.0 to 500.0 | 0.0 to 900.0 | JPt100 | -200.0 to 650.0 | -300.0 to 1,200.0 |
| | 2 | J | -100 to 850 | -100 to 1,500 | --- | Cannot be set. | |
| | 3 | | 0.0 to 400.0 | 0.0 to 750.0 | --- | | |
| | 4 to F | --- | Cannot be set. | | --- | | |


●CompoBus/S I/O Link Unit

| Model number | CP1W-SRT21 |
|--|--|
| Master/slave | CompoBus/S Slave |
| Number of I/O points | 8 input points, 8 output points |
| Number of words allocated in CPU Unit I/O memory | 1 input word, 1 output word |
| Node number setting | Set using the DIP switch (Set before turning on the CPU Unit's power supply.) |

External Interfaces


The CP1E CPU Units provide the following external interfaces.

E10/14/20 or N14/20 CPU Units



Note: Terminal Block (Fixed)


E30/40, N30/40/60 or NA20 CPU Units



Note: Terminal Block (Fixed)


Serial Communications Port for N/NA-type CPU Units

The Serial Communication Port can be used for a CP1E N/NA-type CPU Unit.




Optional Serial Communication Board

| Model number | Port | Maximum transmission distance | Connection method |
|--------------|-------------------------------------|-------------------------------|---------------------------------|
| CP1W-CIF01 | One RS-232C port | 15 m | Connector (D-sub, 9 pin female) |
| CP1W-CIF11 | One RS-422A/485 port (not isolated) | 50 m | Terminal block (using ferrules) |
| CP1W-CIF12 | One RS-422A/485 port (isolated) | 500 m | Terminal block (using ferrules) |
| CP1W-CIF41 | One Ethernet port | 100 m | Connector (RJ45, 8 pin modular) |



Built-in RS-232C Port and CP1W-CIF01 RS-232C Option Board




●RS-232C Connector


| Pin | Abbr. | Signal name | Signal direction |
|----------------|----------|---------------------|------------------|
| 1 | FG | Frame ground | -- |
| 2 | SD (TXD) | Send data | Output |
| 3 | RD (RXD) | Receive data | Input |
| 4 | RS (RTS) | Request to send | Output |
| 5 | CS (CTS) | Clear to send | Input |
| 6 | 5 V | Power supply | -- |
| 7 | DR (DSR) | Data set ready | Input |
| 8 | ER (DTR) | Data terminal ready | Output |
| 9 | SG (0 V) | Signal ground | -- |
| Connector hood | FG | Frame Ground | -- |

Note: Do not use the 5-V power from pin 6 of the RS-232C port for anything but CJ1W-CIF11 RS-422A Conversion Adapter, NT-AL001 RS-232C/RS-422A Conversion Adapter and NV3W-M□20L Programmable Terminal. The external device or the CPU Unit may be damaged.


CP1W-CIF11/CIF12 RS-422A/485 Option Board



●RS-422A/485 Terminal Block



CP1W-CIF41 Ethernet Option Board version 2.0 or higher



●Specifications

| | | |
|------------------|--------------------------------------|--|
| Type | 100/10Base-TX (Auto-MDIX) | |
| Support Software | CX-Programmer version 9.12 or higher | |
| Transfer | Media access method | CSMA/CD |
| | Modulation method | Baseband |
| | Transmission paths | Star form |
| | Baud rate | 100 Mbit/s (100Base-TX) 10 Mbit/s (10Base-TX) • Half/full auto-negotiation for each port • Link speed auto-sensing for each port |
| | Transmission media | • Unshielded twisted-pair (UDP) cable Categories: 5, 5e • Shielded twisted-pair (STP) cable Categories: 100Ω at 5, 5e • Unshielded twisted-pair (UDP) cable Categories: 3, 4, 5, 5e • Shielded twisted-pair (STP) cable Categories: 100Ω at 3, 4, 5, 5e |
| | Transmission Distance | 100 m (distance between hub and node) |
| | Number of cascade connections | No restrictions if switching hubs are used. |

●FINS Communications Service Specifications

| | | |
|-----------------------|--|--|
| Number of nodes | 254 | |
| Message Length | 552 bytes max. | |
| Date Length | 540 bytes max. (except for FINS header 10 byte and Command header 2 byte.) | |
| Number of buffer | 8k byte | |
| Protocol name | FINS/UDP method | FINS/TCP method |
| Protocol used | UDP/IP | TCP/IP |
| | The selection of UDP/IP or TCP/IP is made from the FINS/TCP Tab by the Web browser function. | |
| Number of connections | --- | 2 |
| Port number | 9600 (default) Can be changed. | 9600 (default) Can be changed. |
| Protection | No | Yes (Specification of client IP addresses when unit is used as a server) |

Connecting to Support Software


Operating Environment and System Configuration

The following system is required to operate the CX-Programmer. Make sure your system provides the following conditions and has the necessary components.

| Item | Description |
|-----------------------------|--|
| Supported computer | IBM PC/AT or equivalent |
| CD-ROM or DVD-ROM drive | One or more |
| Supported Operating Systems | Windows 2000 (Service Pack 4 or higher), XP, Vista, or 7 (except 64-bit edition) |
| CPU | Pentium II 333 MHz or faster |
| RAM | 256 MB min. 512 MB or more recommended |
| Available hard disk space | 600 MB min. |
| Display | 800 x 600 SVGA min. |
| PLC and connection port | USB port, RS-232C port, RS-422A/485 port or Ethernet port |

Connecting Methods

Using commercially available USB cable, connect the CX-Programmer to the peripheral USB port on the CPU Unit. Host link connection can be made with RS-232C port to connect the Programming Device (CX-Programmer).



Connecting Cable

Use the following cable to connect the CP1E CPU Unit to the computer running the Support Software.

USB port

| Port at Unit | Port at computer | Network type (communications mode) | Model numbers | Length |
|--|------------------|------------------------------------|--|---------------|
| Peripheral USB port (Conforming to USB 2.0, B connector) | USB port | USB 2.0 (or 1.1) | Commercially available USB cable (A connector - B connector) | Less than 5 m |

RS-232C Port for N/NA-type CPU Units

| Port at Unit | Port at computer | Communications mode | Connecting Cable | | |
|---|------------------|---------------------|------------------|--------|-----------------------------|
| | | | Model | Length | Remarks |
| RS-232C Port or CP1W-CIF01 (Add this to the option board slot.) | RS-232C port * | Host Link (SYSWAY) | XW2Z-200S-CV | 2m | With anti-static connectors |
| | | | XW2Z-500S-CV | 5m | With anti-static connectors |
| | | | XW2Z-200S-V | 2m | --- |
| | | | XW2Z-500S-V | 5m | --- |

Note: Connectable with CX-Programmer Ver.9.1 or higher only.

* Use the USB-Serial Conversion Cable CS1W-CIF31 together to connect a PLC to a personal computer's USB port.

Unit Versions

| Units | Model numbers | Unit version |
|----------------|---|------------------|
| CP1E CPU Units | CP1E-E□□D□-□ CP1E-N□□D□-□ CP1E-NA□□D□-□ | Unit version 1.□ |

Unit Versions and Programming Devices

The following tables show the relationship between unit versions and CX-Programmer versions.

Unit Versions and Programming Devices

| CPU Unit | Functions | Required Programming Device * | | | | | | | |
|---|----------------------------|-------------------------------|--|------------------------------------|---------------------------------|--|------------------------------------|------------------------------------|------------------------------------|
| | | CX-Programmer | | | Micro PLC Edition CX-Programmer | | | | CX-Programmer for CP1E |
| | | Ver.8.1 or lower | Ver.8.2 | Ver.9.03 or higher | Ver.8.1 or lower | Ver.8.2 | Ver.9.0 | Ver.9.03 or higher | Ver.1.0 |
| CP1E-E10D□-□ CP1E-□14D□-□ CP1E-N60D□-□ CP1E-NA20D□-□ | Unit version 1.□ functions | Not support. | Not support. | Yes Supports Smart Input function. | Not support. | Not support. | Not support. | Yes Supports Smart Input function. | Not support. |
| CP1E-E20/30/40D□-A CP1E-N20/30/40D□-□ | Unit version 1.□ functions | Not support. | Yes Does not support Smart Input function. | Yes Supports Smart Input function. | Not support. | Yes Does not support Smart Input function. | Yes Supports Smart Input function. | Yes Supports Smart Input function. | Yes Supports Smart Input function. |

* A Programming Console cannot be used.

Programming Instructions

Sequence Input Instructions

| Instruction | Mnemonic |
|---------------|----------|
| LOAD | LD |
| LOAD NOT | LD NOT |
| AND | AND |
| AND NOT | AND NOT |
| OR | OR |
| OR NOT | OR NOT |
| AND LOAD | AND LD |
| OR LOAD | OR LD |
| NOT | NOT |
| CONDITION ON | UP |
| CONDITION OFF | DOWN |

Sequence Output Instructions

| Instruction | Mnemonic |
|--------------------|----------|
| OUTPUT | OUT |
| OUTPUT NOT | OUT NOT |
| KEEP | KEEP |
| DIFFERENTIATE UP | DIFU |
| DIFFERENTIATE DOWN | DIFD |
| SET | SET |
| RESET | RSET |
| MULTIPLE BIT SET | SETA |
| MULTIPLE BIT RESET | RSTA |
| SINGLE BIT SET | SETB |
| SINGLE BIT RESET | RSTB |

Sequence Output Instructions

| Instruction | Mnemonic |
|---|----------|
| END | END |
| NO OPERATION | NOP |
| INTERLOCK | IL |
| INTERLOCK CLEAR | ILC |
| MULTI-INTERLOCK DIFFERENTIATION HOLD | MILH |
| MULTI-INTERLOCK DIFFERENTIATION RELEASE | MILR |
| MULTI-INTERLOCK CLEAR | MILC |
| JUMP | JMP |
| JUMP END | JME |
| CONDITIONAL JUMP | CJP |
| FOR LOOP | FOR |
| BREAK LOOP | BREAK |
| NEXT LOOP | NEXT |

Timer and Counter Instructions

| Instruction | Mnemonic |
|---------------------|----------|
| TIMER | TIM |
| | TIMX |
| COUNTER | CNT |
| | CNTX |
| HIGH-SPEED TIMER | TIMH |
| | TIMHX |
| ONE-MS TIMER | TMHH |
| | TMHHX |
| ACCUMULATIVE TIMER | TTIM |
| | TTIMX |
| LONG TIMER | TIML |
| | TIMLX |
| REVERSIBLE COUNTER | CNTR |
| | CNTRX |
| RESET TIMER/COUNTER | CNR |
| | CNRX |

Comparison Instructions

| Instruction | Mnemonic |
|--|-----------------|
| Input Comparison Instructions (unsigned) | LD,AND,OR+= |
| | LD,AND,OR+<> |
| | LD,AND,OR+< |
| | LD,AND,OR+<= |
| | LD,AND,OR+> |
| Input Comparison Instructions (double, unsigned) | LD,AND,OR+>= |
| | LD,AND,OR+=+L |
| | LD,AND,OR+<>+L |
| | LD,AND,OR+<+L |
| | LD,AND,OR+<=+L |
| Input Comparison Instructions (double, signed) | LD,AND,OR+>+L |
| | LD,AND,OR+>=+L |
| | LD,AND,OR+=+S |
| | LD,AND,OR+<>+S |
| | LD,AND,OR+<+S |
| Input Comparison Instructions (signed) | LD,AND,OR+<=+S |
| | LD,AND,OR+>+S |
| | LD,AND,OR+>=+S |
| | LD,AND,OR+=+SL |
| | LD,AND,OR+<>+SL |
| Input Comparison Instructions (double, signed) | LD,AND,OR+<+SL |
| | LD,AND,OR+<=+SL |
| | LD,AND,OR+>+SL |
| | LD,AND,OR+>=+SL |
| Time Comparison Instructions | =DT |
| | <>DT |
| | <DT |
| | <=DT |
| | >DT |
| COMPARE | >=DT |
| | CMP |
| | CMPL |
| | CPS |
| | CPSL |
| DOUBLE COMPARE | TCMP |
| SIGNED BINARY COMPARE | BCMP |
| DOUBLE SIGNED BINARY COMPARE | ZCP |
| TABLE COMPARE | ZCPL |
| UNSIGNED BLOCK COMPARE | |
| AREA RANGE COMPARE | |
| DOUBLE AREA RANGE COMPARE | |

Data Movement Instructions

| Instruction | Mnemonic |
|------------------------|----------|
| MOVE | MOV |
| DOUBLE MOVE | MOVL |
| MOVE NOT | MVN |
| MOVE BIT | MOVB |
| MOVE DIGIT | MOVD |
| MULTIPLE BIT TRANSFER | XFRB |
| BLOCK TRANSFER | XFER |
| BLOCK SET | BSET |
| DATA EXCHANGE | XCHG |
| SINGLE WORD DISTRIBUTE | DIST |
| DATA COLLECT | COLL |

Data Shift Instructions

| Instruction | Mnemonic |
|---------------------------|----------|
| SHIFT REGISTER | SFT |
| REVERSIBLE SHIFT REGISTER | SFTR |
| WORD SHIFT | WSFT |
| ARITHMETIC SHIFT LEFT | ASL |
| ARITHMETIC SHIFT RIGHT | ASR |
| ROTATE LEFT | ROL |
| ROTATE RIGHT | ROR |
| ONE DIGIT SHIFT LEFT | SLD |
| ONE DIGIT SHIFT RIGHT | SRD |
| SHIFT N-BITS LEFT | NASL |
| DOUBLE SHIFT N-BITS LEFT | NSLL |
| SHIFT N-BITS RIGHT | NASR |
| DOUBLE SHIFT N-BITS RIGHT | NSRL |

Increment/Decrement Instructions

| Instruction | Mnemonic |
|-------------------------|----------|
| INCREMENT BINARY | ++ |
| DOUBLE INCREMENT BINARY | ++L |
| DECREMENT BINARY | -- |
| DOUBLE DECREMENT BINARY | --L |
| INCREMENT BCD | ++B |
| DOUBLE INCREMENT BCD | ++BL |
| DECREMENT BCD | --B |
| DOUBLE DECREMENT BCD | --BL |

Symbol Math Instructions

| Instruction | Mnemonic |
|---|----------|
| SIGNED BINARY ADD WITHOUT CARRY | + |
| DOUBLE SIGNED BINARY ADD WITHOUT CARRY | +L |
| SIGNED BINARY ADD WITH CARRY | +C |
| DOUBLE SIGNED BINARY ADD WITH CARRY | +CL |
| BCD ADD WITHOUT CARRY | +B |
| DOUBLE BCD ADD WITHOUT CARRY | +BL |
| BCD ADD WITH CARRY | +BC |
| DOUBLE BCD ADD WITH CARRY | +BCL |
| SIGNED BINARY SUBTRACT WITHOUT CARRY | - |
| DOUBLE SIGNED BINARY SUBTRACT WITHOUT CARRY | -L |
| SIGNED BINARY SUBTRACT WITH CARRY | -C |
| DOUBLE SIGNED BINARY SUBTRACT WITH CARRY | -CL |
| BCD SUBTRACT WITHOUT CARRY | -B |
| DOUBLE BCD SUBTRACT WITHOUT CARRY | -BL |
| BCD SUBTRACT WITH CARRY | -BC |
| DOUBLE BCD SUBTRACT WITH CARRY | -BCL |
| SIGNED BINARY MULTIPLY | * |
| DOUBLE SIGNED BINARY MULTIPLY | *L |
| BCD MULTIPLY | *B |
| DOUBLE BCD MULTIPLY | *BL |
| SIGNED BINARY DIVIDE | / |
| DOUBLE SIGNED BINARY DIVIDE | /L |
| BCD DIVIDE | /B |
| DOUBLE BCD DIVIDE | /BL |

Conversion Instructions

| Instruction | Mnemonic |
|-----------------------------|----------|
| BCD-TO-BINARY | BIN |
| DOUBLE BCD-TO-DOUBLE BINARY | BINL |
| BINARY-TO-BCD | BCD |
| DOUBLE BINARY-TO-DOUBLE BCD | BCDL |
| 2'S COMPLEMENT | NEG |
| DATA DECODER | MLPX |
| DATA ENCODER | DMPX |
| ASCII CONVERT | ASC |
| ASCII TO HEX | HEX |

Logic Instructions

| Instruction | Mnemonic |
|---------------------|----------|
| LOGICAL AND | ANDW |
| DOUBLE LOGICAL AND | ANDL |
| LOGICAL OR | ORW |
| DOUBLE LOGICAL OR | ORWL |
| EXCLUSIVE OR | XORW |
| DOUBLE EXCLUSIVE OR | XORL |
| COMPLEMENT | COM |
| DOUBLE COMPLEMENT | COML |

Special Math Instructions

| Instruction | Mnemonic |
|--------------------|----------|
| ARITHMETIC PROCESS | APR |
| BIT COUNTER | BCNT |

Floating-point Math Instructions

| Instruction | Mnemonic |
|----------------------------|-----------------|
| FLOATING TO 16-BIT | FIX |
| FLOATING TO 32-BIT | FIXL |
| 16-BIT TO FLOATING | FLT |
| 32-BIT TO FLOATING | FLTl |
| FLOATING-POINT ADD | +F |
| FLOATING-POINT SUBTRACT | -F |
| FLOATING-POINT DIVIDE | /F |
| FLOATING-POINT MULTIPLY | *F |
| Floating Symbol Comparison | LD, AND, OR+=F |
| | LD, AND, OR+<>F |
| | LD, AND, OR+<F |
| | LD, AND, OR+<=F |
| | LD, AND, OR+>F |
| | LD, AND, OR+>=F |
| FLOATING- POINT TO ASCII | FSTR |
| ASCII TO FLOATING-POINT | FVAL |

Table Data Processing Instructions

| Instruction | Mnemonic |
|----------------|----------|
| SWAP BYTES | SWAP |
| FRAME CHECKSUM | FCS |

Data Control Instructions

| Instruction | Mnemonic |
|-----------------------------|----------|
| PID CONTROL WITH AUTOTUNING | PIDAT |
| TIME-PROPORTIONAL OUTPUT | TPO |
| SCALING | SCL |
| SCALING 2 | SCL2 |
| SCALING 3 | SCL3 |
| AVERAGE | AVG |

Subroutine Instructions

| Instruction | Mnemonic |
|-------------------|----------|
| SUBROUTINE CALL | SBS |
| SUBROUTINE ENTRY | SBN |
| SUBROUTINE RETURN | RET |

Interrupt Control Instructions

| Instruction | Mnemonic |
|--------------------|----------|
| SET INTERRUPT MASK | MSKS |
| CLEAR INTERRUPT | CLI |
| DISABLE INTERRUPTS | DI |
| ENABLE INTERRUPTS | EI |

High-speed Counter and Pulse Output Instructions

| Instruction | Mnemonic |
|---------------------------------|----------|
| MODE CONTROL | INI |
| HIGH-SPEED COUNTER PV READ | PRV |
| COMPARISON TABLE LOAD | CTBL |
| SPEED OUTPUT | SPED |
| SET PULSES | PULS |
| PULSE OUTPUT | PLS2 |
| ACCELERATION CONTROL | ACC |
| ORIGIN SEARCH | ORG |
| PULSE WITH VARIABLE DUTY FACTOR | PWM |

Step Instructions

| Instruction | Mnemonic |
|-------------|----------|
| STEP DEFINE | STEP |
| STEP START | SNXT |

I/O Unit Instructions

| Instruction | Mnemonic |
|--------------------------|----------|
| I/O REFRESH | IORF |
| 7-SEGMENT DECODER | SDEC |
| DIGITAL SWITCH INPUT | DSW |
| MATRIX INPUT | MTR |
| 7-SEGMENT DISPLAY OUTPUT | 7SEG |

Serial Communications Instructions

| Instruction | Mnemonic |
|-------------|----------|
| TRANSMIT | TXD |
| RECEIVE | RXD |

Clock Instructions

| Instruction | Mnemonic |
|-------------------|----------|
| CALENDAR ADD | CADD |
| CALENDAR SUBTRACT | CSUB |
| CLOCK ADJUSTMENT | DATE |

Failure Diagnosis Instructions

| Instruction | Mnemonic |
|----------------------|----------|
| FAILURE ALARM | FAL |
| SEVERE FAILURE ALARM | FALS |

Other Instructions


| Instruction | Mnemonic |
|---------------------------|----------|
| SET CARRY | STC |
| CLEAR CARRY | CLC |
| EXTEND MAXIMUM CYCLE TIME | WDT |

Dimensions


(Unit: mm)

CP1E CPU Unit

●CPU Units with 10 I/O Points




●CPU Units with 14 or 20 I/O Points




●CPU Units with 30 I/O Points


CPU Units with 20 I/O Points and Built-in Analog



●CPU Units with 40 I/O Points




●CPU Units with 60 I/O Points




Expansion I/O Units and Expansion Units


●CP1W-8E□□/CP1W-SRT21



●CP1W-20ED□/CP1W-16E□□/CP1W-AD041/CP1W-DA021/CP1W-DA041/CP1W-MAD11/CP1W-TS□□□



●CP1W-40ED□/CP1W-32E□□



Related Manuals

| Manual name | Cat. No. | Model numbers | Application | Contents |
|--|----------|---|--|---|
| SYSMAC CP Series CP1E CPU Unit Hardware Manual | W479 | CP1E-E□□D□-□ CP1E-N□□D□-□ CP1E-NA□□D□-□ | To learn the hardware specifications of the CP1E PLCs | Describes the following information for CP1E PLCs. <ul style="list-style-type: none"> • Overview and features • Basic system configuration • Part names and functions • Installation and settings • Troubleshooting |
| | | | Use this manual together with the CP1E CPU Unit Software Manual (Cat. No. W480) and CP1E CPU Unit Instructions Reference Manual (Cat. No. W483). | |
| SYSMAC CP Series CP1E CPU Unit Software Manual | W480 | CP1E-E□□D□-□ CP1E-N□□D□-□ CP1E-NA□□D□-□ | To learn the software specifications of the CP1E | Describes the following information for CP1E PLCs. <ul style="list-style-type: none"> • CPU Unit operation • Internal memory • Programming • Settings • CPU Unit built-in functions • Interrupts • High-speed counter inputs • Pulse outputs • Serial communications • Analog I/O function • Other functions |
| | | | Use this manual together with the CP1E CPU Unit Hardware Manual (Cat. No. W479) and CP1E CPU Unit Instructions Reference Manual (Cat. No. W483). | |
| SYSMAC CP Series CP1E CPU Unit Instructions Reference Manual | W483 | CP1E-E□□D□-□ CP1E-N□□D□-□ CP1E-NA□□D□-□ | To learn programming instructions in detail | Describes each programming instruction in detail. When programming, use this manual together with the CP1E CPU Unit Hardware Manual (Cat. No. W479) and CP1E CPU Unit Software Manual (Cat. No. W480). |
| CS/CJ/CP/NSJ Series Communications Commands Reference Manual | W342 | CS1G/H-CPU□□H CS1G/H-CPU□□-V1 CS1D-CPU□□H CS1D-CPU□□S CS1W-SCU□□-V1 CS1W-SCB□□-V1 CJ1G/H-CPU□□H CJ1G-CPU□□P CJ1M-CPU□□ CJ1G-CPU□□ CJ1W-SCU□□-V1 | To learn communications commands for CS/CJ/CP/NSJ-series Controllers in detail | Describes 1) C-mode commands and 2) FINS commands in detail. Read this manual for details on C-mode and FINS commands addressed to CPU Units. |
| | | | Note: This manual describes commands addressed to CPU Units. It does not cover commands addressed to other Units or ports (e.g., serial communications ports on CPU Units, communications ports on Serial Communications Units/Boards, and other Communications Units). | |
| SYSMAC CP Series CP1L/CP1E CPU Unit Introduction Manual | W461 | CP1L-L10D□-□ CP1L-L14D□-□ CP1L-L20D□-□ CP1L-M30D□-□ CP1L-M40D□-□ CP1L-M60D□-□ CP1E-E□□D□-□ CP1E-N□□D□-□ CP1E-NA□□D□-□ | To learn the basic setup methods of the CP1L/CP1E PLCs | Describes the following information for CP1L/CP1E PLCs. <ul style="list-style-type: none"> • Basic configuration and component names • Mounting and wiring • Programming, data transfer, and debugging using the CX-Programmer • Application program examples |

[illegible]

Terms and Conditions of Sale

1. **Offer; Acceptance.** These terms and conditions (these "Terms") are deemed part of all quotes, agreements, purchase orders, acknowledgments, price lists, catalogs, manuals, brochures and other documents, whether electronic or in writing, relating to the sale of products or services (collectively, the "Products") by Omron Electronics LLC and its subsidiary companies ("Omron"). Omron objects to any terms or conditions proposed in Buyer's purchase order or other documents which are inconsistent with, or in addition to, these Terms.
2. **Prices; Payment Terms.** All prices stated are current, subject to change without notice by Omron. Omron reserves the right to increase or decrease prices on any unshipped portions of outstanding orders. Payments for Products are due net 30 days unless otherwise stated in the invoice.
3. **Discounts.** Cash discounts, if any, will apply only on the net amount of invoices sent to Buyer after deducting transportation charges, taxes and duties, and will be allowed only if (i) the invoice is paid according to Omron's payment terms and (ii) Buyer has no past due amounts.
4. **Interest.** Omron, at its option, may charge Buyer 1-1/2% interest per month or the maximum legal rate, whichever is less, on any balance not paid within the stated terms.
5. **Orders.** Omron will accept no order less than \$200 net billing.
6. **Governmental Approvals.** Buyer shall be responsible for, and shall bear all costs involved in, obtaining any government approvals required for the importation or sale of the Products.
7. **Taxes.** All taxes, duties and other governmental charges (other than general real property and income taxes), including any interest or penalties thereon, imposed directly or indirectly on Omron or required to be collected directly or indirectly by Omron for the manufacture, production, sale, delivery, importation, consumption or use of the Products sold hereunder (including customs duties and sales, excise, use, turnover and license taxes) shall be charged to and remitted by Buyer to Omron.
8. **Financial.** If the financial position of Buyer at any time becomes unsatisfactory to Omron, Omron reserves the right to stop shipments or require satisfactory security or payment in advance. If Buyer fails to make payment or otherwise comply with these Terms or any related agreement, Omron may (without liability and in addition to other remedies) cancel any unshipped portion of Products sold hereunder and stop any Products in transit until Buyer pays all amounts, including amounts payable hereunder, whether or not then due, which are owing to it by Buyer. Buyer shall in any event remain liable for all unpaid accounts.
9. **Cancellation; Etc.** Orders are not subject to rescheduling or cancellation unless Buyer indemnifies Omron against all related costs or expenses.
10. **Force Majeure.** Omron shall not be liable for any delay or failure in delivery resulting from causes beyond its control, including earthquakes, fires, floods, strikes or other labor disputes, shortage of labor or materials, accidents to machinery, acts of sabotage, riots, delay in or lack of transportation or the requirements of any government authority.
11. **Shipping; Delivery.** Unless otherwise expressly agreed in writing by Omron:
 - a. Shipments shall be by a carrier selected by Omron; Omron will not drop ship except in "break down" situations.
 - b. Such carrier shall act as the agent of Buyer and delivery to such carrier shall constitute delivery to Buyer;
 - c. All sales and shipments of Products shall be FOB shipping point (unless otherwise stated in writing by Omron), at which point title and risk of loss shall pass from Omron to Buyer; provided that Omron shall retain a security interest in the Products until the full purchase price is paid;
 - d. Delivery and shipping dates are estimates only; and
 - e. Omron will package Products as it deems proper for protection against normal handling and extra charges apply to special conditions.
12. **Claims.** Any claim by Buyer against Omron for shortage or damage to the Products occurring before delivery to the carrier must be presented in writing to Omron within 30 days of receipt of shipment and include the original transportation bill signed by the carrier noting that the carrier received the Products from Omron in the condition claimed.
13. **Warranties.** (a) **Exclusive Warranty.** Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied. (b) **Limitations.** OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) **Buyer Remedy.** Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty. See <http://www.omron247.com> or contact your Omron representative for published information.
14. **Limitation on Liability; Etc.** OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY. Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.
15. **Indemnities.** Buyer shall indemnify and hold harmless Omron Companies and their employees from and against all liabilities, losses, claims, costs and expenses (including attorney's fees and expenses) related to any claim, investigation, litigation or proceeding (whether or not Omron is a party) which arises or is alleged to arise from Buyer's acts or omissions under these Terms or in any way with respect to the Products. Without limiting the foregoing, Buyer (at its own expense) shall indemnify and hold harmless Omron and defend or settle any action brought against such Companies to the extent based on a claim that any Product made to Buyer specifications infringed intellectual property rights of another party.
16. **Property; Confidentiality.** Any intellectual property in the Products is the exclusive property of Omron Companies and Buyer shall not attempt to duplicate it in any way without the written permission of Omron. Notwithstanding any charges to Buyer for engineering or tooling, all engineering and tooling shall remain the exclusive property of Omron. All information and materials supplied by Omron to Buyer relating to the Products are confidential and proprietary, and Buyer shall limit distribution thereof to its trusted employees and strictly prevent disclosure to any third party.
17. **Export Controls.** Buyer shall comply with all applicable laws, regulations and licenses regarding (i) export of products or information; (ii) sale of products to "forbidden" or other proscribed persons; and (iii) disclosure to non-citizens of regulated technology or information.
18. **Miscellaneous.** (a) **Waiver.** No failure or delay by Omron in exercising any right and no course of dealing between Buyer and Omron shall operate as a waiver of rights by Omron. (b) **Assignment.** Buyer may not assign its rights hereunder without Omron's written consent. (c) **Law.** These Terms are governed by the law of the jurisdiction of the home office of the Omron company from which Buyer is purchasing the Products (without regard to conflict of law principles). (d) **Amendment.** These Terms constitute the entire agreement between Buyer and Omron relating to the Products, and no provision may be changed or waived unless in writing signed by the parties. (e) **Severability.** If any provision hereof is rendered ineffective or invalid, such provision shall not invalidate any other provision. (f) **Setoff.** Buyer shall have no right to set off any amounts against the amount owing in respect of this invoice. (g) **Definitions.** As used herein, "including" means "including without limitation"; and "Omron Companies" (or similar words) mean Omron Corporation and any direct or indirect subsidiary or affiliate thereof.

Certain Precautions on Specifications and Use

1. **Suitability of Use.** Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases but the following is a non-exhaustive list of applications for which particular attention must be given:
 - (i) Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.
 - (ii) Use in consumer products or any use in significant quantities.
 - (iii) Energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
 - (iv) Systems, machines and equipment that could present a risk to life or property. Please know and observe all prohibitions of use applicable to this Product.
 NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON'S PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.
2. **Programmable Products.** Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.
3. **Performance Data.** Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.
4. **Change in Specifications.** Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.
5. **Errors and Omissions.** Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.



OMRON ELECTRONICS LLC • THE AMERICAS HEADQUARTERS • Schaumburg, IL USA • 847.843.7900 • 800.556.6766 • www.omron247.com

OMRON CANADA, INC. • HEAD OFFICE

Toronto, ON, Canada • 416.286.6465 • 866.986.6766
www.omron247.com

OMRON ELETRÔNICA DO BRASIL LTDA • HEAD OFFICE

São Paulo, SP, Brasil • 55.11.2101.6300 • www.omron.com.br

OMRON ELECTRONICS MEXICO SA DE CV • HEAD OFFICE

Apodaca, N.L. • 52.811.156.99.10 • 001.800.556.6766 • mela@omron.com

OMRON ARGENTINA • SALES OFFICE

Cono Sur • 54.11.4783.5300

OMRON CHILE • SALES OFFICE

Santiago • 56.9.9917.3920

OTHER OMRON LATIN AMERICA SALES

54.11.4783.5300

OMRON EUROPE B.V. Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands. Tel: +31 (0) 23 568 13 00 Fax: +31 (0) 23 568 13 88 www.industrial.omron.eu